

PESTICIDE SPRAY DRIFT CONFERENCE

Droplet Spectra for Aerial Applicators

Ivan W. "Buddy" Kirk



Agricultural Research Service
U.S. Department of Agriculture



ORIGIN OF STANDARDIZED SPRAY DROPLET SIZE CATEGORIES


- 1985 -- British Crop Protection Council (BCPC)
 - Droplet size classifications, primarily designed to enhance efficacy.
 - Uses the term **SPRAY QUALITY** for droplet size categories.
- 2000 -- ASAE Standard S572
 - Droplet size classifications, primarily designed to control spray drift.
 - Uses the term **DROPLET SPECTRA CLASSIFICATION** for droplet size categories.

DROPLET SPECTRA CLASSIFICATION IS SPECIFIC TERMINOLOGY THAT WILL BE USED ON PRODUCT LABELS AND IS RELATED TO VOLUME MEDIAN DIAMETER FROM AN ASAE REFERENCE NOZZLE SET WITH A LASER REFERENCE INSTRUMENT*

- Very Fine (VF) < 182µm
- Fine (F) 183-280µm
- Medium (M) 281-429µm
- Coarse (C) 430-531µm
- Very Coarse (VC) 532-655µm
- Extremely Coarse (XC) >656µm

*USDA ARS
College Station, TX
PWS

REFERENCE CURVES FOR ASAE S572 REFERENCE NOZZLES PMS SYSTEM, USDA, ARS, COLLEGE STATION, TX




Nozzle Classification Thresholds For ASAE S572

Based on ARS College Station PMS = 182µm 280µm 429µm 531µm 655µm



ARS College Station PMS $D_{v0.5}$ = 177µm 278µm 416µm 517µm 636µm

ASAE Reference Nozzles: 01F110, 03F110, 06F110, 8008, 6510



WHAT DO THESE SIZES MEAN IN RELATIVE TERMS ?

- Very Fine (VF) human hair
- Fine (F) sewing thread
- Medium (M) tooth brush bristle
- Coarse (C) staple
- Very Coarse (VC) paper clip
- Extremely Coarse (XC) #2 pencil lead



THE LABEL IS THE LAW

Directions for use

It is a violation of federal law to use this product in a manner inconsistent with its labeling.

WHAT ARE WE ACCUSTOMED TO SEEING ON LABELS ?

- Use nozzle types and arrangements that will provide optimum spray distribution and maximum coverage . . . Classic, 1998
- The best drift management strategy is to apply the largest droplets that provide sufficient coverage and control. Hyvar X-L, 1998 & Furadan 4F, 1999

-- general statements and precautions --

WHAT NEW TERMS ARE WE SEEING ON LABELS ?

- . . . desired droplet size (100 - 200μm) . . . Lock-On (chlorpyrifos), 2001 (very fine -- fine)
- . . . apply in spray droplet size of 200-300 μm . . . Tracer (spinosad), 2001 (medium)
- . . . use coarse spray droplets . . . (430-530μm) Reclaim (clopyralid), 2001

How do applicators comply with the law when label language is this specific?

PRACTICAL SOURCES FOR DROPLET SPECTRA CLASSIFICATION INFORMATION

- Technical literature
- Nozzle manufacturers literature (ground)
- Spray Drift Task Force database
 - Ground systems
 - Orchard airblast systems
 - Aerial systems
 - DropKick
 - AgDRIFT
 - DropKick
 - USDA aerial nozzle models
- USDA aerial nozzle models

USDA AERIAL NOZZLE MODELS

Applicability and Limitations:

- Specific nozzle class
- Account for airspeed/air shear
- Account for major influence of spray mix properties
- Models currently available
 - Eight fixed-wing nozzle models
 - Eight helicopter nozzle models

NOZZLE USE IN AERIAL APPLICATION

Nozzle Composite Utilization, %

Nozzle	Fixed-wing	Rotary-wing
CP-03	42 *	30 *
CP Str. Stream	25 *	8 †
Disc Orif. Str. Stream	8 *	15 *
Flat Fan	5 **	2 †**
Disc-Core	5 **	12 *
Lund Str. Stream	4 *	2
Accu-Flo	4	16 **
Micronair	3	5
Raindrop RD	2	8 *
Flood	2	
TVB		2



*Nozzle Models Available

AERIAL NOZZLE MODEL DEVELOPMENT

Objective:

- Develop a readily usable tool for aerial applicators to predict Droplet Spectra Classification from predominantly used nozzles in both fixed-wing and rotary-wing segments of the aerial application industry

AERIAL NOZZLE MODEL DEVELOPMENT

Fixed-Wing Study Equipment:

- Wind tunnel test facility
 - Nozzle angle, general: 0° - 90°, low drift: 0° - 20°
 - Nozzle size, range based on survey
 - Airspeed, 100 to 160 mph
 - Pressure, 20 to 60 psi
 - PMS laser probe

AERIAL NOZZLE MODEL DEVELOPMENT

Helicopter Study Equipment:

- Wind tunnel test facility
 - Nozzle angle, general: 0° - 90°, low drift: 0° - 20°
 - Nozzle size, range based on survey
 - Airspeed, 30 to 100 mph
 - Pressure, 20 to 60 psi
 - PMS laser probe





AERIAL NOZZLE MODEL DEVELOPMENT

Study Equipment:

Examples --

- Disc Orifice 46 Core Nozzle
 - Orifice Sizes: 2 - 10
 - Nozzle Angles: 0° - 90°
- CP-03 Nozzle
 - Nozzle axis parallel with airstream
 - Orifice Sizes: 0.061 - 0.171
 - Nozzle Deflector Angles: 30°, 55°, 90°

AERIAL NOZZLE MODEL DEVELOPMENT

Spray Mix:

- Tap water
- 0.25% v/v Triton X-100

AERIAL NOZZLE MODEL DEVELOPMENT

Procedure:

- Experimental Design
 - 27 Different Combinations of
 - Orifice Size, or Nozzle Size
 - Nozzle Angle, or Deflector Angle
 - Spray Pressure
 - Airspeed
 - Each combination scanned in 4 passes with laser spectrometer in wind tunnel and that process was replicated 3 times for each of the 27 combinations for each nozzle

AERIAL NOZZLE MODEL DEVELOPMENT

Procedure:

- PMS laser spectrometer data selection
 - Volume median diameter, $D_{v0.5}$
 - Relative span, RS, measure of range of mid 80% of spray spectrum
 - % Spray volume in droplets < 100 μm diameter
 - % Spray volume in droplets < 200 μm diameter
 - Droplet Spectra Classification (Computed classification based on $D_{v0.5}$ from nozzle under test, reference nozzle dataset, and ASAE S572)

AERIAL NOZZLE MODEL DEVELOPMENT

Data Analysis:

$$Y = A + BX_1 + CX_2 + DX_3 + EX_4 + FX_1^2 + GX_2X_1 + HX_2^2 + IX_3X_1 + JX_3X_2 + KX_3^2 + LX_4X_1 + MX_4X_2 + NX_4X_3 + OX_4^2$$

FIXED-WING NOZZLE MODEL Spreadsheet for Disc Orifice Straight Stream Nozzle

DISC ORIFICE STRAIGHT STREAM NOZZLE
FOR USE ON FIXED-WING AIRCRAFT

Quotation from this work should be as follows: Kirk, I. W. "Droplet Spectra Classification for Fixed-Wing Aircraft Spray Nozzles." Presented at the ASAE 94th Annual International Meeting, Sacramento, CA, July 31, 2001, Paper Number 01-1082.
ASAE, 2950 Niles Rd., St. Joseph, MO 64505-9699 USA, Telephone: (816) 429-0300, Facsimile: (816) 429-3852.
The author is solely responsible for the content of this technical presentation. The technical presentation does not necessarily reflect the official position of ASAE, and its printing and distribution does not constitute an endorsement of views, which may be expressed. The author is I. W. Kirk, Agricultural Engineer, Aircraft Pest Management Research Unit, Southern Plains Agricultural Research Center, Agricultural Research Service, U. S. Department of Agriculture, 2771 F&R Road, College Station, TX 77845-4966, USA.

Directions: Enter DISC ORIFICE nozzle parameters, pressure, and airspeed in the cells highlighted below.
(Application parameters are valid only with nozzle parameters specified in the Acceptable Range.)

Orifice Size,	Nozzle Angle, degrees	Pressure, psi	Airspeed, mph
Acceptable Range: 4 to 12	0 to 20	20 to 60	100 to 160
14	0	30	130

Application parameters are displayed in the box below.

$D_{v0.5}$ = 328 μm	= Volume median diameter
RS = 1.31	= Relative Span
V<100 μm = 5.36 %	= Percentage of spray volume in droplets smaller than 100 μm diameter.
V<200 μm = 14.04 %	= Percentage of spray volume in droplets smaller than 200 μm diameter.
DSC = MEDIUM	= Droplet Spectra Classification.

CAUTION: Do not enter or clear data in the cells in this box!

Technical presentations are not subject to the formal peer review process by ASAE editorial committees, therefore they are not to be presented as endorsed publications. Trade names are mentioned solely for the purpose of providing specific information. Mention of a trade name does not constitute a guarantee or warranty of the product by the U. S. Department of Agriculture, or ASAE, and does not imply endorsement of the product over other products not mentioned.

FIXED-WING NOZZLE MODEL Spreadsheet for Disc Orifice Straight Stream Nozzle

DISC ORIFICE STRAIGHT STREAM NOZZLE
FOR USE ON FIXED-WING AIRCRAFT

Quotation from this work should be as follows: Kirk, I. W. "Droplet Spectra Classification for Fixed-Wing Aircraft Spray Nozzles." Presented at the ASAE 94th Annual International Meeting, Sacramento, CA, July 31, 2001, Paper Number 01-1082.
ASAE, 2950 Niles Rd., St. Joseph, MO 64505-9699 USA, Telephone: (816) 429-0300, Facsimile: (816) 429-3852.
The author is solely responsible for the content of this technical presentation. The technical presentation does not necessarily reflect the official position of ASAE, and its printing and distribution does not constitute an endorsement of views, which may be expressed. The author is I. W. Kirk, Agricultural Engineer, Aircraft Pest Management Research Unit, Southern Plains Agricultural Research Center, Agricultural Research Service, U. S. Department of Agriculture, 2771 F&R Road, College Station, TX 77845-4966, USA.

Directions: Enter DISC ORIFICE nozzle parameters, pressure, and airspeed in the cells highlighted below.
(Application parameters are valid only with nozzle parameters specified in the Acceptable Range.)

Orifice Size,	Nozzle Angle, degrees	Pressure, psi	Airspeed, mph
Acceptable Range: 4 to 12	0 to 20	20 to 60	100 to 160
10	0	30	120


Application parameters are displayed in the box below.

$D_{v0.5}$ = 518 μm	= Volume median diameter
RS = 1.32	= Relative Span
V<100 μm = 0.92 %	= Percentage of spray volume in droplets smaller than 100 μm diameter.
V<200 μm = 3.15 %	= Percentage of spray volume in droplets smaller than 200 μm diameter.
DSC = COARSE	= Droplet Spectra Classification.


CAUTION: Do not enter or clear data in the cells in this box!

Technical presentations are not subject to the formal peer review process by ASAE editorial committees, therefore they are not to be presented as endorsed publications. Trade names are mentioned solely for the purpose of providing specific information. Mention of a trade name does not constitute a guarantee or warranty of the product by the U. S. Department of Agriculture, or ASAE, and does not imply endorsement of the product over other products not mentioned.

AERIAL NOZZLE MODEL Validation of Model Predictions



40° FLAT FAN NOZZLE MODEL GRAPHS 4008 Orifice Tip, 0° Nozzle Angle



AERIAL NOZZLE MODELS

Summary:

- Use of these aerial nozzle models will permit users of aerial nozzles to be responsible stewards in the use of crop protection materials
- Regulatory decisions on details of use of these models will facilitate compliance with label requirements for aerial application with a specific spray droplet spectra classification

AERIAL NOZZLE MODELS

Availability:

- Diskettes with spreadsheet models will be provided based on request
- Interactive models are posted on USDA ARS APMRU Internet homepage
- USDA will publish an Aerial Applicators Spray Nozzle Handbook based on the models
- NAAA has committed to purchase copies of the Handbook for distribution to NAAA members, additional copies will be available from GPO, NTIS

AERIAL NOZZLE MODELS

Availability:

USDA ARS APMRU Internet homepage for access to aerial spray nozzle models:

<http://apmru.usda.gov>
Downloads

-- TIME FOR QUESTIONS --



Agricultural Research Service
U.S. Department of Agriculture

