

**Study Protocol 170: Surface Water Monitoring for Forest Herbicides  
in the Karuk Aboriginal Territory**

**Nan Singhasemanon**

October 1998



**STATE OF CALIFORNIA  
Environmental Protection Agency  
Department of Pesticide Regulation  
Environmental Monitoring and Pest Management Branch  
Environmental Hazards Assessment Program  
830 K Street  
Sacramento, California 95814-3510**

**Study 170**

Department of Pesticide Regulation  
Environmental Monitoring and Pest Management  
1020 N Street, Room 161  
Sacramento, California 95814-5624

**Study 170: Surface Water Monitoring for Forest Herbicides in the  
Karuk Aboriginal Territory**

APPROVALS

*Beneé Stauffer*  
*Katherine Glaze*  
*Ara S. Smith*  
*[Signature]*  
Karuk Tribe of California

8/27/98  
8/27/98  
8/27/98

8-27-98  
Date

*[Signature]*  
Sponsor (U.S. EPA)

9/9/98  
Date

*[Signature]*  
Management (Dept. Pesticide Regulation)

7-15-98  
Date

*[Signature]*  
Study Director (Dept. Pesticide Regulation)

7/14/98  
Date

*[Signature]*  
Field Quality Assurance Officer  
(Dept. Pesticide Regulation)

7/8/98  
Date

Department of Pesticide Regulation  
Environmental Monitoring and Pest Management  
1020 N Street, Room 161  
Sacramento, California 95814-5624

## **Study 170: Surface Water Monitoring for Forest Herbicides in the Karuk Aboriginal Territory**

**September 16, 1998**

### **I. INTRODUCTION**

In California, approximately 50% of the state's 32 million acres of forested lands consist of timber stands of harvestable quality (Barrett, 1995). Government agencies, private companies, and private individuals own these lands, and may manage some or all of their lands for commercial timber production. The timber industry employs intense forest management practices, particularly in regions where fire or overcutting has resulted in large losses of harvestable timber. Reforestation practices are used to establish new conifer stands in these low density regions. These practices generally involve the use of forest herbicides to control the growth of unwanted vegetative material prior to planting, during site preparation, and timber stand improvement following conifer establishment (Green and Cohn, 1982).

In northwestern California, Native Americans have voiced concern over the use of reforestation herbicides on private forest land watersheds, in addition to general pesticide use in agricultural valleys which lie adjacent to Native American territorial lands. Studies have shown that forest herbicide residues may be transported off-site in rain and/or snow melt runoff water (Carlson and Fiore, 1993). Also, agricultural irrigation drain water may transport pesticide residues off-site during the summer months when drain water is typically released from agricultural fields (Dileanis et al., 1996). Consequently, residents in these rural forest communities, who rely on surface water as a drinking water source, have expressed concern about the presence of pesticide residues in water.

This northwestern forest land is characterized by extreme physiographic conditions with mountain areas that rise as high as 9,000 feet. Because of the steep slopes and lithic makeup, this area is very susceptible to landslides (California Department of Forestry, 1979). In addition, the rainfall average ranges from 20 to 100 inches per year (Barrett, 1995) and the surface water supply originates from a massive network of smaller

watersheds linked by streams throughout the hydrologic basin (California Department of Forestry, 1979).

The Native Americans of northwestern California have requested that the California Department of Pesticide Regulation (DPR) and the U.S. Environmental Protection Agency (EPA) Office of Pesticide Programs monitor surface waters for herbicides used in reforestation practices in that region. Herbicides to be monitored include atrazine, hexazinone, 2,4-dichlorophenoxyacetic acid (2,4-D), glyphosate, and triclopyr, all of which are compounds currently registered in California for forestry use. Also, when appropriate, DPR will include a pesticide screen to analyze surface waters for several additional pesticide compounds in the carbamate, organophosphate, phenoxy, and triazine/uracil/urea classes.

## **II. OBJECTIVE**

This project is an investigation to determine the presence of pesticide residues in surface waters of concern in the Karuk Aboriginal Territory. If the results of this study indicate that pesticide residues are present in surface waters, then further investigation may be warranted to determine the extent of the problem and possible pesticide sources. If necessary, mitigation measures may later be proposed.

## **III. SPONSOR**

Annie Yates,  
US EPA  
Office of Pesticide Program  
75 Hawthorne St.  
San Francisco, California

## **IV. COLLABORATORS**

Leaf Hillman, LaVerne Glaze, Renee Stauffer, Ora Smith  
The Karuk Environmental Monitoring Work Group  
The Karuk Tribe of California  
P.O. Box 282  
Orleans, CA 95556

## **V. TESTING FACILITIES AND PERSONNEL**

The testing facilities are located at:

Department of Pesticide Regulation  
Environmental Hazards Assessment Program  
830 K St.  
Sacramento, California 95814

Department of Pesticide Regulation  
Environmental Hazards Assessment Program  
3971 Commerce Drive, Suite D  
West Sacramento, California 95691

California Department of Food and Agriculture  
Center for Analytical Chemistry  
3292 Meadowview Road  
Sacramento, California 95832

This cooperative sampling effort will be conducted by DPR's Environmental Hazards Assessment Program (EHAP) staff, Karuk tribal representatives, U.S. EPA, and the County Agricultural Commissioners' staff, under the general direction of Kean S. Goh, Program Supervisor.

Key personnel are listed below:

Project Leader:	Nan Singhasemanon
Senior Staff Scientist:	Lisa Ross
Field Coordinator:	DeeAn Jones
Statistician:	Terri Barry
Quality Assurance/Lab Liaison:	Carissa Ganapathy
Chemist:	Catherine Cooper
Contact Person:	Madeline Brattesani

Responsibilities of key personnel are described in EHAP Standard Operating Procedure ADMN002.00 (Supplement 1). Authorship of the final report may include but not limited to the personnel named above.

Questions concerning this monitoring study should be directed to either 1) Madeline Brattesani at (916) 324-4100; fax, (916) 324-4088; e-mail, [mbrattesani@cdpr.ca.gov](mailto:mbrattesani@cdpr.ca.gov). or 2) Kean Goh (same telephone and fax numbers as those given for Madeline Brattesani); e-mail, [kgoh@cdpr.ca.gov](mailto:kgoh@cdpr.ca.gov).

## **VI. TEST SUBSTANCES**

There are numerous substances that will be monitored for in surface water. These substances can be categorized into five pesticide groups based on the structural formula of each compound. These groups are the carbamates, organophosphates, phenoxys, triazines, and miscellaneous groupings. Individual pesticide compounds in these groups will include, but are not limited to the following:

**Carbamates:** Aldicarb, carbaryl, carbofuran, methiocarb, methomyl, and oxamyl.

**Organophosphates:** Azinphos-methyl, chlorpyrifos, DDVP, diazinon, dimethoate, ethoprop, fonofos, methyl parathion, malathion, methidathion, phosalone, phosmet, and thimet.

**Phenoxys:** 2,4-D, MCPA, and triclopyr.

**Triazines/Uracil/Urea:** Atrazine, bromacil, diuron, cyanazine, hexazinone, metribuzin, prometon, prometryn, and simazine.

**Miscellaneous:** Glyphosate.

## **VII. SELECTION OF TEST SYSTEM**


The test system will be surface water sites located in northwestern California. All sites will be selected by participants in the study based on accessibility, water flow, and importance to the local Native American Tribes.

## **VIII. EXPERIMENTAL DESIGN/STUDY PLAN**

### **A. Surface Water - General Investigation**

A general investigation for pesticide residues in surface water will be conducted at three sites. These sites will be sampled approximately eight times in the study year (1998-1999). With the exception of the first sampling event under dry conditions, field crews will attempt to coordinate subsequent sampling with storm runoff events. The first storm runoff after a major pesticide application period upstream of the sampling sites will be closely monitored. Periodic sampling over the course of the runoff event may be necessary in order to detect peak concentrations of pesticides. Overall, increasing the frequency of sampling at key sites was favored over increasing the number of sampling sites to maximize the likelihood of detecting pesticides.

**Figure 1: Lower Klamath/Trinity Rivers Region**



At a previous meeting, the Karuk Tribal representatives had named several sampling sites that were of interest. These included the Klamath River, Scott River, Lake Oogarmotok, and several creeks: Cheenitch, Crawford, Elk, Indian, Pearch, Red Cap, Wilder, and Wooley (see map on the following page). We proposed to sample the Klamath River and Scott River at some location before they converge. Because there is documented forest herbicide and agricultural pesticide use upstream of these proposed sites, the collected river water samples will be analyzed for all 32 compounds listed in Section VI.

An additional site at Elk Creek will be monitored for the five forest herbicides and the remaining triazine/urea/uracil class herbicides (a total of 13 compounds). Elk Creek is proposed due to its importance as a domestic water supply, its accessibility, and its appreciable flow through out the year.

#### **B. Surface Water - Focussed Sampling Sites**

Stormwater or snowmelt runoff samples may also be collected immediately downstream of an area recently applied with forest herbicides. These locations will be referred to as “focussed sampling sites”. Locations of focussed sampling sites will be determined during the course of the study. DPR will be working closely with the Humboldt and Siskiyou Agricultural Commissioner’s Office to track forest herbicide applications which are adjacent to waterways that are of interest to the Karuk Tribe. Pesticides to be analyzed will depend upon the specific forest herbicides applied adjacent to these sites. Sampling at these sites is likely to be a one-time event.

### **IX. SAMPLING METHODS, SAMPLE STORAGE, SAMPLE TRANSPORT, AND CHEMICAL ANALYTICAL METHODS**

#### **A. Water and Environmental Sampling Methods. Sample Storage, Transport, and Tracking Procedures.**

When possible, composite water samples will be collected from a bridge site using an equal width increment method for sampling surface water (EHAP SOP FSWA003.00, Supplement 2). If the use of this method proves to be impractical at certain sites, a simpler depth-integrated or grab method may be used instead. The actual sampling method used for each event will be documented in the chain-of-custody forms and the field notebook. Collected surface water samples will then be split and preserved according to methods reported in EHAP SOP FSWA004.00 (Supplement 3). For the general investigation sites near agricultural areas, a minimum of eight liters of water is needed to analyze for the 32 pesticide compounds in surface water: one sample for each type of analysis: a) carbamate analysis (requires acidification with 3N HCl), b) glyphosate analysis, c) phenoxy analysis, d) triazine analysis, e) organophosphate analysis (requires acidification with 3N HCl), f) diazinon analysis, g) acidified backup, and h) unacidified backup. Although diazinon is an organophosphate, it requires a



separate bottle which is not to be acidified. The water to be used for the carbamate and organophosphate analyses will be acidified to a pH of 3.0 to 3.5 in the field to reduce pesticide dissipation prior to chemical analyses.

For general investigation sites which are not expected to receive agricultural runoff, a minimum of four liters of water is needed to analyze for 13 pesticide compounds: a) glyphosate analysis, b) phenoxy analysis for 2,4-D and triclopyr, c) triazine analysis, and d) unacidified backup.

All water samples will be stored on wet ice and maintained at 4°C as described in EHAP SOP QAQC004.00 (Supplement 4) until chemically extracted. Sample tracking is described in EHAP SOP QAQC003.00 (Supplement 5). Results will be reported in µg/L.

Environmental parameters such as air temperature, water temperature, pH, dissolved oxygen, and electrical conductivity will be recorded at each site for each sampling period.

## **B. Analytical Method**

Chemical analyses for pesticides in surface water will be performed by the California Department of Food and Agriculture Laboratory. All method validation work has been completed for all 32 compounds and was done according to EHAP SOP QAQC001.00 (Supplement 6).

Each analyte's spike levels used for method validation were based on the range of concentrations anticipated in surface water. The mean recovery and standard deviation were calculated for each compound. Warning limits were established at the mean recovery plus two times the standard deviation and the mean recovery minus two times the standard deviation. Control limits were established at the mean recovery plus three times the standard deviation and the mean recovery minus three times the standard deviation.

Method Detection Limits were determined according to EHAP SOP QAQC001.00 and the U.S. EPA procedure (40 CFR, Part 136, Appendix B). The Method Detection Limit for each chemical in water is given in the analytical method. Sampling and chemical analysis will not occur until all necessary analytical methods have been written and approved for all test compounds.

## **C. Quality Assurance/Quality Control**

Laboratory continuing quality control will follow EHAP SOP QAQC001.00 and include the following: Matrix Blank: 1 matrix blank per extraction set and Matrix Spike: 1 matrix spike sample per extraction set. Any matrix spike samples falling outside the warning or control limits will have the appropriate steps taken as described in EHAP SOP

QAQC001.00. Blind matrix spikes will be periodically submitted to the CDFA laboratory for analysis.

For field quality control, a set of equipment/rinse blanks (one for each analysis) will be taken by each crew per each sampling day. These blanks will help determine if the splitting equipment was adequately cleaned. The collection of these blanks will follow EHAP SOP QAQC006.00 (Supplement 7).

## **IX. DATA ANALYSIS**

Descriptive statistics will be used to characterize surface water data.

## **X. ESTIMATED TIMETABLE AND NUMBER OF SAMPLES**

Sampling is expected to occur periodically through the 1998-1999 study year, and subsequently, intermittent progress reports will be issued to interested parties prior to completion of the final report.

Chemical Analytical Method Development: June 1998

Sampling Period: September 1998 through September 1999

Chemical Analyses: September 1998 through September 1999

Status Progress Report: Summer 1998, Winter 1998, and Spring 1999

Final Report: June 2000

The total number of water samples anticipated to be collected in this study is 168 (120 surface water samples + 48 rinse blanks.)

## **XI. RECORDS TO BE MAINTAINED**

The following documents will be maintained at the testing facility as described in SOP ADMN005.00 (Supplement 8).

1. All raw data other than those records maintained by the laboratory.
2. The study protocol bearing the original signatures of the study director, sponsor, and quality assurance officers, including amendments and documentation of deviations.
3. All correspondence necessary to reconstruct the study.
4. All progress reports and audits
5. Documentation of the training and experience of personnel involved in the study.
6. A copy of the final report.

## **XII. REFERENCES**

Barrett, J. 1995. Regional silviculture of the United States. Third Ed., John Wiley and Sons, Inc., New York, New York.

Bovey, R. and A. Young. 1980. The science of 2,4,5-T and associated phenoxy herbicides. John Wiley and Sons. Printed in the United States of America.

California Department of Forestry. 1979. Forest resources assessment and analysis. Sacramento, California.

Carlson, J. and H. Fiore. 1993. Water monitoring report: 1991 herbicide application projects, El Dorado National Forest. U.S. Forest Service.

Dileanis, P.D., S.E. Schwarzbach, and J. Bennett. 1996. Detailed study of water quality, bottom sediment, and biota associated with irrigation drainage in the Klamath Basin, California and Oregon, 1990-92. U. S. Geological Survey - Water-Resources Investigations Report 95-4232. Sacramento, California.

Green, K. and K. Cohn. 1982. Forests, herbicides and people. Faculty Press, Inc., Brooklyn, New York.

## **SUPPLEMENT 1**

**STANDARD OPERATING PROCEDURE**  
**Personnel Organization and Responsibilities for Studies**

---

**KEY WORDS**

management; project supervisor; project leader; senior scientist; field coordinator;  
quality assurance officer; laboratory liaison; statistician; chemist; contact person; GLP;  
safety; problem resolution

**APPROVALS**

APPROVED BY:

John L. Sanders  
Management

DATE:

3/6/97

APPROVED BY:

K L Z...  
EHAP Senior Scientist

DATE:

3-5-97

APPROVED BY:

Randy Segawa  
EHAP Quality Assurance Officer

DATE:

2-26-97

PREPARED BY:

Randy Segawa

DATE:

2-26-97

No previous SOP exists; however, this SOP does supersede the following policy memos:

Goh, K.S. Responsibilities of Field Coordinator for EHAP studies. Memorandum to EHAP Personnel, dated 9/24/93.

Sanders, J. Responsibilities of Project Leaders Regarding Chemical Analysis. Memorandum to EHAP Staff, dated 6/13/88.

Sanders, J. Lab Liaison Personnel and Policy. Memorandum to EHAP Personnel, dated 7/1/87.

## STANDARD OPERATING PROCEDURE

### Personnel Organization and Responsibilities for Studies

---

## 1.0 INTRODUCTION

### 1.1 Purpose

This Standard Operating Procedure (SOP) defines and discusses the organization and responsibilities of personnel for Environmental Hazards Assessment Program (EHAP) studies. This SOP primarily applies to EHAP field studies, but can also apply to non-field projects.

### 1.2 Definitions

**1.2.1 Branch** refers to an organizational unit within the Department of Pesticide Regulation (DPR). There are six branches within DPR as shown in Figure 1.

**1.2.2 Protocol** refers to a written document that describes the objectives, personnel, study design, sampling procedures, analytical procedures, data analysis, and schedule for a specific study.

### 1.3 EHAP Organization

The EHAP is a unit within the Department of Pesticide Regulation (DPR) and provides technical support and monitoring regarding the environmental fate of pesticides. The department and organization of program personnel are shown in Figure 1.

## 2.0 STUDY ORGANIZATION

Figure 1 shows that the EHAP is organized into groups by function or technical specialty. Personnel are organized into a team for each study. Key study personnel include the Management, Project Supervisor, Project Leader, Senior Scientist, Field Coordinator, Laboratory Liaison, Quality Assurance Officer, Statistician, Chemist and Contact Person. The personnel listed above may not be included in all studies. With certain restrictions, the duties of two or more people may be performed by one person (e.g., the duties of the Project Supervisor and Project Leader may be performed by a single person). The most common personnel organization for a study is shown in Figure 2. The Project Supervisor is selected by the branch chief and/or program supervisor. The Project Leader and other team members are selected by the program supervisor and group supervisors. Selection of all team members should be made

## STANDARD OPERATING PROCEDURE

### **Personnel Organization and Responsibilities for Studies**

---

early in the developmental stages of a study to allow them time to understand what management wants to accomplish and to allow sufficient time to prepare for implementing the study.

### **3.0 PERSONNEL RESPONSIBILITIES**

The following personnel have specific responsibilities when assigned to a study.

**3.1 Management** - Management typically consists of the Assistant Director and Branch Chief and sometimes the Program Supervisor. Management has responsibility for all policy issues, including the following:

- 3.1.1 determines the objective of a study
- 3.1.2 selects the project supervisor
- 3.1.3 gives final approval for the study protocol, including the budget
- 3.1.4 gives final approval for all SOPs
- 3.1.5 gives approval to any changes in finalized protocols
- 3.1.6 sets study deadlines
- 3.1.7 gives final approval for the study report and any interim memos

**3.2 Project Supervisor** - The Project Supervisor is typically the supervisor of the Project Leader (i.e., a senior environmental research scientist (supervisor) or the Program Supervisor). The Project Supervisor has overall responsibility for the administrative and technical aspects of the study, including the following:

- 3.2.1 refines the study objectives
- 3.2.2 selects the Project Leader
- 3.2.3 gives general direction to the Project Leader
- 3.2.4 acts as editor-in-chief for review of documents (e.g. protocol, memos, SOPs, report)
- 3.2.5 reviews and approves any changes in finalized protocols
- 3.2.6 supervises administrative tasks (e.g., contracts, purchases, hires)
- 3.2.7 supplies personnel and resources to the Project Leader
- 3.2.8 establishes responsibilities of each team member - consulting with Project Leader
- 3.2.9 facilitates communication with other groups and other branches
- 3.2.10 responsible for safety - determines safety procedures and disseminates hazard communication information - consulting with other DPR branches
- 3.2.11 helps resolve scientific differences of opinion

## **STANDARD OPERATING PROCEDURE**

### **Personnel Organization and Responsibilities for Studies**

---

If the study is conducted under Good Laboratory Practices (GLP), the Project Supervisor is assigned to Management and is also responsible for the following:

- 3.2.12 establishes a quality assurance unit
- 3.2.13 assures that test and control substances or mixtures have been tested for identity, strength, purity, stability and uniformity
- 3.2.14 assures that any deviations from GLP are communicated to the Study Director (Project Leader) and corrective actions are taken and documented

**3.3 Project Leader** - The Project Leader is typically an environmental research scientist (ERS), associate ERS, or a senior ERS. The Project Leader has primary responsibility for all technical aspects of a study, including the following duties. Some of the following responsibilities may be delegated to other team members.

- 3.3.1 gathers background information for study - conducts literature search, gathers pesticide use data
- 3.3.2 identifies personnel needs - sampling, chemical analysis, data analysis
- 3.3.3 formulates study plan after consulting with team members
- 3.3.4 writes and follows study protocol and any changes
- 3.3.5 coordinates protocol dissemination with contact person
- 3.3.6 communicates with study cooperators - growers, agencies
- 3.3.7 specifies lab goals through lab liaison - methodology, validation, reporting limits, quality control, turnaround time
- 3.3.8 interacts with interested parties through the contact person - agencies, public
- 3.3.9 develops chain of custody form - consults with team members
- 3.3.10 conducts administrative tasks - contracts, timesheets, purchases, services, budget, expenditures tracking
- 3.3.11 documents all study activities
- 3.3.12 obtains necessary permits
- 3.3.13 determines sampling methodology - consulting with team members
- 3.3.14 determines sampling schedule - consulting with field coordinator
- 3.3.15 prepares all pertinent SOPs
- 3.3.16 trains personnel in study tasks
- 3.3.17 supervises field sampling and/or data collection
- 3.3.18 arranges for special facilities - storage, experimental plots
- 3.3.19 determines sample priorities for lab analysis



## STANDARD OPERATING PROCEDURE

### Personnel Organization and Responsibilities for Studies

---

- 3.3.20 reviews and accepts data from the lab
- 3.3.21 designates samples for reanalysis
- 3.3.22 reviews laboratory SOPs
- 3.3.23 supervises data analysis
- 3.3.24 writes interim progress reports or memos
- 3.3.25 writes final report - with other team members
- 3.3.26 coordinates report dissemination with contact person
- 3.3.27 archives study data
- 3.3.28 presents results to various audiences

If the study is conducted under GLP, the Project Leader is designated as the Study Director and is also responsible for the following:

- 3.3.29 corrective actions are taken and documented when necessary
- 3.3.30 GLP requirements are followed

**3.4 Senior Scientist** - The Senior Scientist is typically a senior ERS (specialist). The duties of the Senior Scientist and Project Leader cannot be performed by a single person. The Senior Scientist reviews and approves a study for scientific adequacy, including the following specific duties:

- 3.4.1 gives technical advice to the Project Leader
- 3.4.2 reviews and approves protocols, memos, SOPs (including lab SOPs) and reports for scientific adequacy
- 3.4.3 helps resolve scientific differences of opinion
- 3.4.4 reviews and approves revisions to protocols and SOPs
- 3.4.5 reviews and approves final report

If the study is conducted under GLP, the Senior Scientist is assigned to the Quality Assurance Unit and assists the Quality Assurance Officer.

**3.5 Field Coordinator** - The Field Coordinator is typically an associate ERS, ERS, or environmental research assistant from one of the field groups. The Field Coordinator oversees the collection of field samples and has responsibility for field safety. He/She may have more or fewer duties depending on the preference of the Project Supervisor and Project Leader. The Field Coordinator will normally act for the Project Leader in the Project Leader's absence. More than one Field Coordinator may be assigned for very complex studies. The Field Coordinator is normally responsible for the following duties:

## **STANDARD OPERATING PROCEDURE**

### **Personnel Organization and Responsibilities for Studies**

---

- 3.5.1 decides safety issues under direction of Project Supervisor - the Field Coordinator has the authority to modify or terminate any field activity which threatens the health or safety of field personnel; provides or arranges for safety training
- 3.5.2 assembles sampling materials
- 3.5.3 purchases needed materials
- 3.5.4 arranges transportation and housing
- 3.5.5 checks and calibrates equipment
- 3.5.6 assists in developing chain of custody format
- 3.5.7 assists in coordinating activities with study cooperators
- 3.5.8 assists in selecting sampling sites
- 3.5.9 gives advice on sampling methodology
- 3.5.10 assists in the preparation of SOPs
- 3.5.11 recommends personnel needs and sampling schedule
- 3.5.12 prepares sampling materials list
- 3.5.13 collects and transports samples
- 3.5.14 coordinates sampling schedule with the Lab Liaison
- 3.5.15 cleans sampling materials
- 3.5.16 supervises field sampling in the absence of the Project Leader
- 3.5.17 assists in the protocol preparation
- 3.5.18 assists in the report preparation

**3.6 Quality Assurance Officer** - The Quality Assurance Officer is typically an associate ERS. Duties of the Quality Assurance Officer and Laboratory Liaison are typically performed by one person. The Quality Assurance Officer cannot perform the duties of the Project Leader or Field Coordinator. The Quality Assurance Officer is responsible for documentation and the quality of the laboratory analysis, including the following specific duties:

- 3.6.1 assists the Project Leader in specifying laboratory methodology
- 3.6.2 assists the Project Leader in specifying laboratory quality control procedures
- 3.6.3 reviews and approves EHAP SOPs
- 3.6.4 maintains copies of protocols and EHAP SOPs
- 3.6.5 reviews, compiles and disseminates quality control data
- 3.6.6 notifies Project Leader of analytical problems
- 3.6.7 initiates lab corrective actions - consulting with Project Leader
- 3.6.8 arranges the preparation of quality control samples

## STANDARD OPERATING PROCEDURE

### Personnel Organization and Responsibilities for Studies

---

- 3.6.9 resolves lab discrepancies
- 3.6.10 produces method validation and quality control tables for the report
- 3.6.11 obtains and disseminates laboratory SOPs
- 3.6.12 reviews laboratory SOPs

If the study is conducted under GLP, the Quality Assurance Officer supervises the Quality Assurance Unit and is responsible for the following:

- 3.6.13 maintains master schedule of EHAP GLP studies
- 3.6.14 determines that all known deviations from the protocol or SOPs were authorized and documented
- 3.6.15 prepares and signs statement of dates of inspection and findings to be included in final report
- 3.6.16 reviews and approves protocol and final report

**3.7 Laboratory Liaison** - The Laboratory Liaison is typically an associate ERS. Duties of the Laboratory Liaison and Quality Assurance Officer are typically performed by one person. The Laboratory Liaison is responsible for coordinating activities between EHAP and the chemistry labs, including the following duties:

- 3.7.1 acts as liaison between the Project Leader and the labs
- 3.7.2 selects the chemistry laboratories (primary and quality control)
- 3.7.3 negotiates analytical specifications with the labs (described in SOP QAQC001)
- 3.7.4 stores and transports samples to the labs
- 3.7.5 controls timing and quantity of samples delivered to the lab
- 3.7.6 tracks movement of samples between storage facility and lab
- 3.7.7 transmits lab data to the Project Leader
- 3.7.8 administers lab contracts

**3.8 Chemist** - The Chemist typically works for the Department of Food and Agriculture or a commercial lab, not EHAP. The Chemist is responsible for the pesticide analysis of samples. He/she also gives advice on sampling methodology.

**3.9 Statistician** - The Statistician is typically an associate ERS. The Statistician is responsible for the design and statistical analysis of the study, including the following specific duties:

- 3.9.1 determines the study design - consulting with other team members
  - 3.9.2 assists in writing the protocol
-

## STANDARD OPERATING PROCEDURE

### Personnel Organization and Responsibilities for Studies

---

- 3.9.3 reviews and approves the study protocol and any changes
- 3.9.4 conducts statistical analysis of the study data
- 3.9.5 assists in writing the final report
- 3.9.6 reviews final report

**3.10 Contact Person** - The Contact Person is typically assigned from Program Representation of the Environmental Monitoring Branch. The Contact Person acts as liaison with the public, branches, and agencies that are interested but not participants in the study. His/Her specific duties include the following:

- 3.10.1 develops interested parties list - consulting with the Project Leader
- 3.10.2 acts as liaison to public/branches/agencies
- 3.10.3 disseminates appropriate documents to interested parties
- 3.10.4 coordinates review of documents with interested parties
- 3.10.5 assists the DPR communications office with media inquiries
- 3.10.6 writes executive summary
- 3.10.7 advises Project Leader on policy and regulatory issues of study

**3.11 Other EHAP and DPR Personnel** - Designated personnel provide support services. EHAP warehouse personnel provide storage, maintenance, equipment and transportation upon request. EHAP laboratory facilities are available for soil characterization and other analyses upon request. A number of people within and outside of EHAP provide special computer services such as programs, databases, modeling, geographic information systems, or graphics upon request. The Worker Health and Safety, and Medical Toxicology Branches can provide information on toxicity, safety precautions as well as medical monitoring upon request. These support personnel may not be available for all studies and should be requested through the Project Supervisor or the appropriate Group Supervisor.

## 4.0 PROBLEM RESOLUTION

Technical items that are not specified here are the responsibility of the Project Leader. Both the Project Leader and Senior Scientist should agree on all technical issues. The Project Supervisor is responsible for resolving any disagreements. Administrative, policy or other items not specified here are the responsibility of the Project Supervisor.

STANDARD OPERATING PROCEDURE  
**Personnel Organization and Responsibilities for Studies**

---

## **5.0 SAFETY**

Personnel safety is of primary importance at all times. The Project Supervisor and Field Coordinator have primary responsibility for safety. However, all team members must follow correct safety procedures. Approval for changing the protocol or a SOP should be sought whenever possible, but may not be possible if an imminent danger exists. A study should always be conducted in a safe manner, no matter what the protocol or SOP specifies. Document all changes in the protocol or SOP.

In the absence of the Field Coordinator, the ranking field group person has primary responsibility for safety while working in the field.

## **6.0 STUDY-SPECIFIC DECISIONS**

Management, Project Supervisor and Project Leader are responsible for the following study-specific decisions:

- 6.1 Selection of study personnel
- 6.2 Responsibilities of each team member

## **7.0 REFERENCES**

Goh, K.S. Responsibilities of Field Coordinator for EHAP studies. Memorandum to EHAP Personnel, dated 9/24/93.

Sanders, J. Responsibilities of Project Leaders Regarding Chemical Analysis. Memorandum to EHAP Staff, dated 6/13/88.

Sanders, J. Lab Liaison Personnel and Policy. Memorandum to EHAP Personnel, dated 7/1/87.

## **APPENDICES**

Figure 1. Department of Pesticide Regulation Personnel Organization

Figure 2. EHAP Study Personnel Organization

## **SUPPLEMENT 2**


STANDARD OPERATING PROCEDURE  
*Equal-Width-Increment Sampling of Surface Waters*


---

**KEY WORDS**


Field sampling; water quality; discharge; contamination

**APPROVALS**

APPROVED BY:  DATE: 2/13/98  
Management

APPROVED BY:  DATE: 2/5/98  
EHAP Senior Scientist

APPROVED BY:  DATE: 2/9/98  
EHAP Quality Assurance Officer

PREPARED BY:  DATE: 2/5/98

Environmental Hazards Assessment Program (EHAP) organization and personnel such as management, senior scientist, quality assurance officer, project leader, etc. are defined and discussed in SOP ADMN002.

**1.0 INTRODUCTION**

**1.1 Purpose**

This Standard Operation Procedure (SOP) discusses the specific procedure for sampling surface water using the equal-width-increment (EWI) method. A cross-sectional depth-integrated sample obtained by the EWI method gives a sample volume proportional to the amount of flow at each of several equally spaced verticals in the cross section. This document gives instruction on A) determining the number of verticals, B) determining a transit rate, and C) collection of a sample volume.

## STANDARD OPERATING PROCEDURE

### *Equal-Width-Increment Sampling of Surface Waters*

---

#### 1.2 Definitions

In the context of this SOP, surface water is defined as all inland waters, excluding groundwater, which are suitable for use as a source of domestic, municipal, or agricultural water supply and which provide habitat for fish and wildlife.

#### 2.0 MATERIALS

- 2.0.1 D-77 Sampling Unit
- 2.0.2 Bridge Board/Crane and Reel
- 2.0.3 5/16" Nozzle/Cap Assembly
- 2.0.4 3-liter Teflon<sup>®</sup> Bottle
- 2.0.5 Tag-line or Tape Measurer
- 2.0.6 Composite Sample Container

#### 3.0 PROCEDURES

Instructions included here are modified from the following document: Edwards, T.K. and D.G. Glysson. Field Methods for Measurement of Fluvial Sediment, U.S. Geological Survey Open-File Report 86-531. pp. 61-64.

##### 3.1 Number of Verticals

- 3.1.1 Looking downstream, measure the perpendicular distance from the left edge of water to the right edge of water.
- 3.1.2 Visually inspect the stream from bank to bank, observing the velocity and depth distribution as well as apparent distribution of sediment in the cross section.
- 3.1.3 Determine the size of the interval that represents approximately 10% of the flow at that part of the cross section where the "unit width discharge" is highest (generally the deepest, fastest section). This increment must be used for the entire cross section. Typically, this works out to be from 10 to 20 increments for streams 5 feet wide.



## STANDARD OPERATING PROCEDURE

### ***Equal-Width-Increment Sampling of Surface Waters***

---

- 3.1.4 For example, if the stream width determined from the tag-line or tape measurer is 160 feet and the width of each increment was determined to be 16 feet, then the number of verticals required is 10. The sample station within each width increment is located at the center of the increment. In this example, the first sampling station would be at 8 feet from the bank nearest the initial point for width measurement. The verticals are then spaced 16 feet apart, resulting in sample stationing at 24, 40, 56, 72, ..... and 152 feet of width.
- 3.1.5 If stream is < 5 feet wide, divide into as many equal increments as possible, with the minimum increment width being 3 inches.

### **3.2 Transit Rate**

- 3.2.1 Determine the vertical increment that contributes the greatest flow to the stream channel (the fastest and deepest). Determine the mean vertical velocity using a current meter. The bronze D-77 operates at velocities up to 7.2 feet per second, and the aluminum D-77 to 3.3 feet per second.
- 3.2.2 Set up D-77 sampling unit at vertical determined from step 3.2.1 and lower unit until the bottle nozzle is just above the surface of the stream.
- 3.2.3 Using a stopwatch, determine the rate (cranks/second) and number of transits that it takes to fill the sampling bottle without overfilling. (A bottle is overfilled when the water surface in the bottle is above the nozzle or air exhaust with the sampler held level.) Several iterations will be required to determine the final transit rate, and this transit rate must be used at each vertical. It is possible to sample at two or more verticals using the same bottle if the bottle is not overfilled.

### **3.3 Sample Collection**

- 3.3.1 Set up D-77 sampling unit (with crank and gauge) at first vertical station and lower until the bottle nozzle is just above the water surface and reset depth gauge to zero.

STANDARD OPERATING PROCEDURE  
***Equal-Width-Increment Sampling of Surface Waters***

---

3.3.2 Using the transit rate determined in step 3.2.3, lower unit into stream and raise to surface once bottom is felt. The movement of the sampling unit throughout the water column must be constant with minimal disturbance of the stream bottom. Continue across stream to its far edge, depositing vertical samples into a composite sample container. Complete necessary transects, until desired volume is obtained. **Note: *An equal number of transits must be made at each vertical.***

#### **4.0 STUDY-SPECIFIC DECISIONS**

Study specific information should be included in the study protocol, a separate document describing a specific study.

#### **5.0 REFERENCES**

Standard Operating Procedure: ADMN002.00. 1996. Personnel organization and responsibilities for studies. California EPA, Department of Pesticide Regulation, Environmental Hazards Assessment Program. Sacramento, CA.

## **SUPPLEMENT 3**

STANDARD OPERATING PROCEDURE


**Instructions for Splitting Water and Rinsing the Geotech® Dekaport Splitter and Splitting Equipment**

---

**KEY WORDS-**


Splitter; rinse; cross-contamination

**APPROVALS**

APPROVED BY:  DATE: 6/22/98  
Management

APPROVED BY:  DATE: 6/1/98  
EHAP Senior Scientist

APPROVED BY:  DATE: 6/18/98  
EHAP Quality Assurance Officer

PREPARED BY:  DATE: 6/18/98

Environmental Hazards Assessment Program (EHAP) organization and personnel such as management, senior scientist, quality assurance officer, project leader, etc. are defined and discussed in SOP ADMN002.

## STANDARD OPERATING PROCEDURE

### Instructions for Splitting Water and Rinsing the Geotech® Dekaport Splitter and Splitting Equipment

---

## 1.0 INTRODUCTION

### 1.1 Purpose

To ensure effective mixing and splitting of a surface water sample when various paired analyses are to be performed and to describe proper cleaning of equipment to prevent cross-contamination.

### 1.2 Scope

This document will provide specific instructions for splitting surface water samples and rinsing the splitter.

## 2.0 MATERIALS

2.1 Large glass jars, stainless steel milk can or container large enough to hold sample water that will be split

2.2 Water sample

2.3 Geotech® 10 port splitter

2.4 Sample containers

2.5 Stainless steel buckets, funnel


2.6 Chain of Custody records

2.7 Latex gloves

2.8 Deionized water (3 or more gallons)

2.9 Leveler

2.10 Large Plastic Bags



## 3.0 PROCEDURES

Samples should be transported in a glass or stainless steel container on wet ice (4°C), from collection site to the site where splitting will occur.

### 3.1 Splitting Procedure

3.1.1 Place the pre-cleaned (see EQWA001) Geotech® dekaport water splitter on level ground. Make sure all splitter water spouts are level to ensure

## STANDARD OPERATING PROCEDURE

### **Instructions for Splitting Water and Rinsing the Geotech® Dekaport Splitter and Splitting Equipment**

---

a fairly even water flow. Place a level across the top of the splitter to ensure that it is level.

3.1.2 Set up to a maximum of 10 sample containers under each Teflon port. If exactly 10 1-liter sample containers (or smaller) are required, use one port per container. If less than 10 samples are required, use fewer ports, or two tubes can be placed in each container. However, all bottles must be treated the same way each time a sample of water is to be split so that each sample contains the same amount of water and sediment. When there are more than ten sample bottles, e.g. 15, then divide the splitter spouts between two buckets and pour the water through the splitter. Then pour the water from one bucket through the splitter into half the sample bottles, then pour the water from the other bucket through the splitter into the remaining bottles. Collect excess water from unused spouts in an uncontaminated bucket or preferably a container used to hold the water sample originally (e.g., a Teflon sampling bottle). This water can be poured through the splitter again to fill the bottles completely.

3.1.3 Immediately before pouring collected sample water into the splitter, mix water inside a glass or stainless steel sample collection container to suspend the sediment. If more than one container was used to collect the sample, mix the separate containers together in a larger container such as a stainless steel milk can. Prior to completely pouring the remainder of the sample water out of the sample containers into the milk can, or into the splitter directly, swirl the water one last time to ensure that all the remaining sediment stays with the sample water and not at the bottom or along the sides of the container.

3.1.4 While pouring the sample water through the splitter, keep the water level near the top of the reservoir chamber so that as much head pressure is maintained as possible to ensure even flow through the spouts. Again, prior to pouring out the last of the sample water, swirl to get the sediment suspended.

3.1.5 Cap all sample containers and rinse the splitting equipment as described below.

STANDARD OPERATING PROCEDURE

**Instructions for Splitting Water and Rinsing the Geotech® Dekaport Splitter and Splitting Equipment**

---

3.2 Rinsing Procedure

3.2.1 If the splitting is conducted at a facility, rather than out in the field, rinse the splitter and all equipment thoroughly with tap water, then proceed to the next step. If splitting is conducted in the field, rinse the splitter and all equipment with deionized-distilled water and add one rinse (see 3.2.3 below).

3.2.2 Rinse the splitter and associated equipment after splitting any water sample by pouring approximately 2 L of deionized water into either the milk can or steel bucket used in the splitting procedure. Then swirl the water to wash out residues. Pour that same water into the next piece of equipment (such as another bucket that was used for splitting), and again swirl the water and pour into another piece of equipment. This continues through all the equipment and ends by pouring the deionized water through the splitter.

3.2.3 This process is completely repeated from start to finish three times, each time with new, uncontaminated 2L volume of deionized water. If initial rinse did not include tap water, as in 3.2.1, then rinse with deionized water once more.

3.2.4 Cover all containers and the splitter with clean plastic bags between uses.

## **SUPPLEMENT 4**



**STANDARD OPERATING PROCEDURE**  
***Packaging and Transporting Samples***

---

**KEY WORDS**

ice chest, water, soil, ice, temperature

**APPROVALS**

APPROVED BY: John S. Sanders DATE: 3/6/97  
Management

APPROVED BY: H. L. Davis DATE: 2-22-97  
EHAP Senior Scientist

APPROVED BY: Randy Segawa DATE: 2-27-97  
EHAP Quality Assurance Officer

PREPARED BY: [Signature] DATE: 2-24-97

Environmental Hazards Assessment Program (EHAP) organization and personnel such as management, senior scientist, quality assurance officer, project leader, etc. are defined and discussed in SOP ADMN002.

## **STANDARD OPERATING PROCEDURE**

### ***Packaging and Transporting Samples***

---

## **1.0 INTRODUCTION**

### **1.1 Purpose**

This Standard Operating Procedure (SOP) defines the approved method for packaging and transporting Environmental Hazards Assessment Program (EHAP) field samples.

## **2.0 EQUIPMENT**

- 2.1 Ice chests
- 2.2 Wet ice or blue ice for cooling water samples
- 2.3 Blue ice or dry ice for cooling soil samples
- 2.4 Appropriate packing material for sample containers
- 2.5 Permanent black marker
- 2.6 White label tape
- 2.7 Thermometer (accurate to 1°C and meets National Institute of Standards and Technology tolerances for accuracy.)
- 2.8 Bubble plastic or other packaging material

## **3.0 PROCEDURE AT SHIPPING POINT**

- 3.1 Place samples in styrofoam holders or other size containers in ice chests immediately after sampling. Pack samples securely by either adding packing material or wrapping containers in bubble plastic in order to prevent breakage.
- 3.2 Add sufficient wet ice or blue ice to chill **water** or **vegetation** samples to 4°C. Add sufficient dry ice to chill **soil** or **air** samples to -10°C. The Project Leader will specify in the protocol the appropriate storage temperature.
- 3.3 Chain of custody records must accompany samples at all times and should be filled out according to SOP ADMN006.
- 3.4 If the study is conducted under Good Laboratory Practices, a high/low or recording thermometer should be placed in each ice chest.

California Department of Pesticide Regulation  
Environmental Hazards Assessment Program  
1020 N Street  
Sacramento, CA 95814

SOP Number: QAQC004.00  
Previous SOP: none  
**Page 3 of 3**

**STANDARD OPERATING PROCEDURE**  
***Packaging and Transporting Samples***

---

**4.0 PROCEDURE AT DESTINATION**

- 4.1 Condition of samples (broken or leaking samples, etc.) should be noted on the corresponding chain of custody record.
- 4.2 Notify the EHAP QA officer of any samples broken during transportation.
- 4.3 Note the temperature on the thermometer inside the ice chest and record on the check-in sheet for each set of samples.

## **SUPPLEMENT 5**

California Department of Pesticide Regulation  
Environmental Hazards Assessment Program  
1020 N Street  
Sacramento, CA 95814

SOP Number: QAQC003.00  
Previous SOP: none  
Page 1 of 7

**STANDARD OPERATING PROCEDURE**  
**Sample Tracking Procedures**

---

**KEY WORDS**

Sample Tracking, Sample Tracking Database, Chain-of custody, Sample

**APPROVALS**

APPROVED BY: John L. Sanders DATE: 3/6/97  
Management

APPROVED BY: H. L. Br... DATE: 3-5-97  
EHAP Senior Scientist

APPROVED BY: Randy Seamus DATE: 2-26-97  
EHAP Quality Assurance Officer

PREPARED BY: Andrea Hoffman DATE: 2-26-97

---

## STANDARD OPERATING PROCEDURE Sample Tracking Procedures

---

### 1.0 INTRODUCTION

#### 1.1 Purpose

This Standard Operating Procedure (SOP) discusses sample check-in and check-out procedures; the recording of chemistry data; sample disposal procedures; and the Sample Tracking Database.

#### 1.2 Definitions

A **sample** is any environmental substance collected and analyzed for chemical content.

**Chain-of-custody** is a record describing in detail all pertinent information specific to each sample, including dates and signatures of persons handling the sample.

**Sample Tracking Database** is a relational database designed in Microsoft Access to trace a sample from the time it is checked into the storage facility until the sample is submitted to a laboratory for analysis or disposed of after a study is completed.

### 2.0 SAMPLE TRACKING

#### 2.1 Sample Tracking Codes

Sample tracking codes are abbreviations for fields in the database that refer to specific information about each sample. The study number in combination with the sample number is identified as the key field and all information specific to the sample is referenced by the following codes back to the key field.

##### **SAMPLE CODES:**

P= Primary

R= Replicate

B= Backup

FB= Field Blank

\* = Split

S= Spike

BG= Background

BM= Blank Matrix

A= Acidified

U= Unacidified

RB= Rinse Blank

## STANDARD OPERATING PROCEDURE

### Sample Tracking Procedures

---

**STORAGE LOCATION CODES** refer to the storage location of each sample at the storage facility.

F= Fresno	R= Refrigerator	SRI 0= Sacramento Refrigerator #1 0
R= Riverside	F= Freezer	SFO7= Sacramento Freezer #07
S= Sacramento	A= Air Temp.	D= Deep Freeze
W= Warehouse	L= Lab	

**SAMPLE TYPE CODES** refer to the sample matrix collected.

FRU= Fruit	DVEG= Dislodgeable Vegetation	TWG= Twigs
SOI= Soil	SSS= Stainless Steel Sheets	EXT= Extract
WAT= Water	LOV= Lo-Vol	STD= Standard
VEG= Vegetation	HIV= Hi-Vol	SUR= Surrogate
SED= Sediment	FILT= Filtrate	TUR= Turf
TAN= Tank	KIM= Kimbie	SAN= Sand
AIR= Air	TRP= Air Cassettes	BRA= Branch

**SAMPLE CONTAINER CODES** refer to the type of container each sample is placed in during storage.

QMSJ= Quart Mason Jar	1 LAMBR= 1 Liter Amber Bottle
PMSJ= Pint Mason Jar	HPMSJR= Half Pint Mason Jar
PBAG= Plastic Bag	HIVJAR= Hi-Vol Jar
FOIL= Aluminum Sheets	P500mL= Plastic Bottle (500 mL)
CAS= Air Cassettes	1 LPC= 1 Liter Polycarb. Bottle
ILPP= 1 Liter Polyprop. Container	VIAL= Small Standard Vial

500mLPC= 500mL Polycarb. Container  
250mLAMBR= 250mL Amber Bottle  
500mLAMBR= 500mL Amber Bottle  
500mLHDPP= 500mL High Density Polyprop.

## STANDARD OPERATING PROCEDURE

### Sample Tracking Procedures

---

**LABORATORY CODES** refer to the specific laboratory each sample is shipped to for analysis.

QUAN= Quanterra Laboratory  
ATL= Aquatic Toxicology Lab  
FMC= FMC Corporation  
ZEN= Zeneca Ag Products  
APPL= Ag and Priority Pollut Labs  
NCL= North Coast Labs  
FRES= Fresno Soils Lab

CDFA= CA Dept. of Food & Agr.  
CDFG= CA Dept. of Fish & Game  
ALTA= ALTA Analytical Laboratory  
VAL= Valent Dublin Laboratory  
MOR= Morse Laboratories Inc.  
UCD= University California Davis  
WSAC= W. Sacramento Soils Lab

**ANALYSIS TYPE** refers to the type of test method to be performed on each sample.

C= Chemical  
O= Organic  
T= Texture

F= Tracer  
P= pH  
B= Bulk Density

E= Elisa  
M= Moisture  
V= Various

## 2.2 Sample Check-in Procedures

All samples received at the storage facility are immediately put in a refrigerator or freezer depending on the matrix specific storage requirements. The field crew fills out a two-part check-in sheet (Figure A) using the sample tracking codes listed in section 2.1.



## STANDARD OPERATING PROCEDURE

### Sample Tracking Procedures

---

The check-in sheet must be complete in order to properly track environmental samples. The following is a description of each key component of the check-in sheet.

**Project ID:** The study number or name.

**Date Received:** The date the sample was received from the field crew.

**Checked-in by:** The initials of the person who fills out the check-in sheet.

**Remarks:** List any additional or necessary information regarding the samples listed on the check-in sheet.

**EHAP Sample No.:** The number assigned to a labeled sampling container.

**Sample Code:** List sample code (Section 2.1 for codes).

**Date Sample Collected:** Note the sample collection date.

**Sample Type:** Specify the type of sample collected (Section 2.1).

**Container Type:** What the sample is stored in (Section 2.1).

**Analysis Type:** The type of analysis the sample is intended for (Section 2.1).

**Analysis:** List the type of chemical the sample is to be analyzed for.

**Comment:** Space provided for additional information regarding individual samples.

**Date/Logged in by:** The date and person who enters information into the Sample Tracking Database.

**Storage Location:** List where the sample is being stored (Section 2.1).

After the check-in sheet is completed, each field sample is compared against its corresponding chain-of-custody (COC), then signed and dated by the sample custodian receiving the sample. The white and yellow copies of the each COC is removed and sent with its corresponding field sample to the laboratory. The pink copy is used to enter the information into the Sample Tracking Database. The pink copy is then sent to the Project Leader. Any remaining samples held at the storage facility are stored under their required storage conditions with the white and yellow copies of their corresponding COCs.

## STANDARD OPERATING PROCEDURE

### Sample Tracking Procedures

---

#### 2.3 Sample Check-out Procedures

A two-part check-out sheet is filled out for any sample leaving the storage facility (Figure B). The check-out sheet must be complete in order to properly track environmental samples leaving the storage facility.

The check-out sheet is similar to the check-in sheet but differs in three components.

**Date Delivered:** The date the sample is taken to the laboratory.

**Checked-out by:** The initials of the person filling out and transporting the sample to the laboratory.

**Laboratory Delivering to:** Specify the destination code for the sample scheduled for analysis (Section 2.1).

A pink copy of the check-out sheet, and white and yellow copy of each COC are sealed in a plastic bag and accompany samples transported to the laboratory. The samples are then placed in ice chests and cooled to their required temperatures using blue ice, wet ice or dry ice. Ice chests are sealed with tape and labelled with the date and initials of the sample custodian using a permanent black marker. The white copy of the check-out sheet is retained by the QA/QC officer and is also used to enter information into the Sample Tracking Database.

#### 2.4 Chemistry Results

After results are received from the laboratory, the laboratory sample number, extraction and analysis date for each sample are entered into the Sample Tracking Database using the appropriate Microsoft Access query.

## **STANDARD OPERATING PROCEDURE**

### **Sample Tracking Procedures**

---

#### **2.5 Sample Disposal**

After each study is completed and with the approval of the Project Leader, all remaining samples stored in the storage facility may be disposed of by the sample custodian. A two-part Sample Disposal Sheet is completed and includes information similar to the check-out sheet (Figure C). This information is then entered into the Sample Tracking Database using the appropriate Microsoft Access query. The white copy of the Sample Disposal Sheet is retained by the QA/QC officer while the yellow copy is used to enter the information into the database.

#### **3.0 Sample Tracking Database**

All the information reported on the check-in, check-out, chemistry result, and sample disposal sheets is entered in the Sample Tracking Database using tables in Microsoft Access. Queries, forms and reports are designed specifically for each study to access fields for summarizing data.

##### **3.1 Computer Generated Backups**

Daily and weekly backups are conducted using Norton software and a tape drive. Diskettes are also used as a source for daily backup of individual study files.

SAMPLE CHECK-IN SHEET  
30-007 (4/90)

Today s Date: \_\_\_\_\_

Logged in by: \_\_\_\_\_  
(key data entry person)

Storage location: \_\_\_\_\_  
(see # on outside of storage)

Remarks:

EHAP Sample No.	Sample Code	Date Sample Collected	Sample Type	Container Type	Analysis Type	Analysis	Comment
--------------------	----------------	--------------------------	----------------	-------------------	------------------	----------	---------

## DEPARTMENT OF PESTICIDE REGULATION

SACRAMENTO SOILS LABORATORY  
3971 COMMERCE DRIVE, SUITE D  
WEST SACRAMENTO, CA 95691  
(916) 322-3082

SAMPLE CHECK-OUT SHEET  
30-008 (4/90)

Today's Date: \_\_\_\_\_

Project ID (Study no.): \_\_\_\_\_

Logged out by: \_\_\_\_\_  
(key data entry person)

Date Delivered: \_\_\_\_\_

Storage location: \_\_\_\_\_  
(see # on outside of storage)

Checked-out by: \_\_\_\_\_

Laboratory Delivering to: \_\_\_\_\_

Remarks:

EHAP Sample No.	Sample Code	Date Sample Collected	Sample Type	Container Type	Analysis Type	Analysis	Comment
--------------------	----------------	--------------------------	----------------	-------------------	------------------	----------	---------

Today's Date: \_\_\_\_\_

EHAP Sample #	Sample Code	EHAP Sample #	Sample Code	EHAP Sample #	Sample Code	EHAP Sample #	Sample Code
------------------	----------------	------------------	----------------	------------------	----------------	------------------	----------------

## **SUPPLEMENT 6**

**STANDARD OPERATING PROCEDURE**  
***Chemistry Laboratory Quality Control***

---

**KEY WORDS**

QC; method detection limit; MDL; reporting limit; RL; confirmation; verification; AB 2021; method development; method validation; storage stability; split; spike; blank; laboratory specifications

**APPROVALS**

APPROVED BY:

John S. Sanders  
Management

DATE:

7/31/95

APPROVED BY:

Heidi L. Bue  
EHAP Senior Scientist

DATE:

7/31/95

APPROVED BY:

Randy Segura  
EHAP Quality Assurance Officer

DATE:

7/28/95

PREPARED BY:

Randy Segura

DATE:

7/28/95

Environmental Hazards Assessment Program (EHAP) organization and personnel such as management, senior scientist, quality assurance officer, project leader, etc. are defined and discussed in SOP ADMN002.



## STANDARD OPERATING PROCEDURE *Chemistry Laboratory Quality Control*

---

### 1.0 INTRODUCTION

#### 1.1 Purpose

This Standard Operating Procedure (SOP) discusses the chemistry laboratory quality control (QC). These guidelines describe method development as well as continuing quality control procedures that should be followed for all Environmental Hazards Assessment Program (EHAP) studies.

#### 1.2 Definitions

1.2.1 **AB 2021 Confirmation** refers to the detection of a pesticide in at least two discrete well samples.

1.2.2 **AB 2021 Verification** refers to analysis "by a second analytical method or a second analytical laboratory approved by the department." Confirmation and verification are defined and discussed at length (particularly in the AB 2021 context) in the memorandum from Randy Segawa to Kean Goh, dated 11/22/93.

1.2.3 **Analytical Confirmation** refers to an analyte that has been unequivocally identified. For an analytical method that is nonspecific (e.g., gas chromatography with a flame photometric detector) analytical confirmation requires a second analysis that has a change in both the separation and detection principle. Except for AB 2021 projects, an analytical method that is specific (e.g., mass spectrometry) meets the analytical confirmation criterion and a second analysis is not required. AB 2021 requires a second analysis even if the primary method is specific.

1.2.4 **Blank** refers to a sample with no detectable amount of pesticide. Blanks are used to check for contamination or to prepare QC samples (e.g., **blank-matrix**, **reagent blank**, and **field blank** samples).

1.2.5 **Blind Spike** refers to a blank-matrix sample which has been spiked and submitted to the lab disguised as a field sample.

1.2.6 **Extract** refers to the final solvent which contains the pesticide residue.

STANDARD OPERATING PROCEDURE  
*Chemistry Laboratory Quality Control*

---

1.2.7 **Extraction Set** refers to a single group of samples extracted and processed at the same time.

1.2.8 **Instrument Detection Limit (IDL)** is 1 - 5 times the signal-to-noise ratio depending on the analytical method.

1.2.9 **Method Detection Limit (MDL)** refers to the USEPA definition (40 CFR, Part 136, Appendix B). "The MDL is defined as the minimum concentration of a substance that can be measured and reported with 99% confidence that the analyte concentration is greater than zero and is determined from analysis of a sample in a given matrix...."

1.2.10 **Reporting Limit (RL)** is 1 - 5 times the MDL depending on the analytical method and matrix. The MDL can vary from sample to sample because of matrix effects. Ideally, the RL will not change, will be set high enough to account for matrix effects, yet low enough to be useful.

1.2.11 **Spike** refers to a known amount of pesticide added. These QC samples are used to check the precision and accuracy of a method.

1.2.12 **Split** refers to one homogeneous sample divided into several aliquots, with the different aliquots analyzed by different laboratories. These QC samples are used to check the specificity and precision of a method.

1.2.13 **Standard** refers to the laboratory analytical standard.

## 2.0 GENERAL PROCEDURES

These guidelines are meant to be a starting point; a specific study may require more or less QC than is given here. The procedures outlined here are the QC measures which should be reported. Performing other QC procedures such as frequency of standard injections and calibrations are left to the chemist's discretion.

**STANDARD OPERATING PROCEDURE**  
***Chemistry Laboratory Quality Control***

---

**2.1 General Method Development**

Many times the method development will be a negotiation between the project leader and the laboratory. The project leader can suggest some method performance goals (e.g., specificity, reporting limit, etc.), but the goals need to be balanced with laboratory cost and time constraints. The method performance should be consistent with the study objectives.

**2.1.1 *Standard*** - Standard solutions should be validated prior to use by checking for chromatographic purity or verification of the concentration using a second standard prepared at a different time or obtained from a different source.

**2.1.2 *Method Detection Limit Determination*** - The MDL is determined by the USEPA method (40 CFR, Part 136, Appendix B). The complete procedure is given in Appendix 1. Briefly, the MDL is determined by analyzing at least 7 low-level matrix spikes (generally 1 - 5 times the IDL) and performing the following calculation:

$$\text{MDL} = t \times S$$

where:

t = Student's t value for 99% confidence level (1-tailed) and n-1 degrees of freedom  
S = standard deviation

**2.1.3 *Reporting Limit Determination*** - The RL is determined by the chemist and set at 1 - 5 times the MDL depending on the matrix and instrument.

**2.1.4 *Method Validation*** - At the onset of a study, an acceptable range of spike recoveries will be established. This range will be established by analyzing blank-matrix spike samples. Two to five replicate analyses at two to five different spike levels will be used to determine the mean percent recovery and standard deviation. Number of replicates and spike levels will be chosen by the project leader. Warning limits will be established at the mean percent recovery plus/minus 1 - 2 times the standard deviation. Control limits will be established at the mean percent recovery plus/minus 2 -

**STANDARD OPERATING PROCEDURE**  
***Chemistry Laboratory Quality Control***

---

3 times the standard deviation. Any subsequent spiked samples outside the control limits may require the set of samples associated with that spike to be reanalyzed.

**2.1.5 Storage Stability** - Storage stability needs to be evaluated on a case-by-case basis, so no specific test design is specified. However, in general the test should be run for the longest anticipated holding period, with at least four sampling intervals and two replicate samples at each sampling interval. Other factors may also need to be incorporated into the storage stability tests, such as pH, temperature, and container type. The project leader is responsible for specifying the design of the storage stability test.

**2.2 General Continuing QC** - These analyses are to be done by the main lab on a continuing basis. Each extraction set should consist of 5-20 actual samples. Exact frequency of QC analyses and spike levels are chosen by the project leader.

**2.2.1 Reagent Blanks** - 1 - 2 per extraction set

**2.2.2 Blank-Matrix Spikes** - 1 - 3 per extraction set

**2.2.3 Analytical Confirmation** - 0 to 100% (normally 10%) of positive samples confirmed

**2.2.4 Split Matrix Samples** - 0 to 100% (normally 10%) of the actual samples should be split into two aliquots, one aliquot analyzed by the main lab, and one by the QC lab. For studies that cannot have actual samples split or for which only a few positives are anticipated, blind spike samples may be used.

**2.2.5 Blind Spikes** - 0 to 100% (normally 10%) of the actual samples should be accompanied by laboratory-spiked samples disguised as real samples. These should be done only for matrices that can be accurately spiked.

**STANDARD OPERATING PROCEDURE**  
***Chemistry Laboratory Quality Control***

---

**2.3 Optional Continuing QC** - The following analyses should be considered but may not be routinely performed unless specified by the project leader.

2.3.1 *Internal Standard* - a chemical not expected in the samples can be spiked into all samples or extracts. This is particularly useful for quantifying mass spectrometry data.

2.3.2 *Replicate Sample Analyses* - analyzing multiple aliquots of a single sample will give a better estimate of the method precision.

2.3.3 *Replicate Extract Analyses* - multiple analyses of a single extract will give a separate estimate of the precision of the extraction and analysis processes.

2.3.4 *Split Extract Analyses* - analyzing a single extract with more than one lab is useful for checking discrepancies between laboratories.

2.3.5 *Reference Material* - a stable sample that contains the analyte(s) of interest and has been analyzed many times so that the concentration(s) are known. Analysis of this material may give a better estimate of the method's accuracy than spiked samples. Also useful for method development.

2.3.6 *Standards Exchange* - exchanging analytical standards between the primary and QC lab is useful for checking discrepancies in split samples.

**3.0 WELL WATER STUDY QC PROCEDURES**

**3.1 Well Water Study Method Development** - The general method development procedures should be used.

**3.2 Well Water Study Continuing QC** - The following specific continuing QC should be used in place of the general continuing QC:

3.2.1 *Reagent Blanks* - 1 to 2 per extraction set

3.2.2 *Blank-Matrix Spikes* - 1 to 3 per extraction set

## STANDARD OPERATING PROCEDURE

### ***Chemistry Laboratory Quality Control***

---

3.2.3 *AB 2021 confirmation and verification* - at least one additional sample from the same well must be analyzed by a second lab or a second method for each positive sample. AB 2021 confirmation requires positive detection in at least 2 discrete samples and verification with a second lab or a second method.

3.2.4 *Blind Spikes* - 1 blind spike should be submitted for every 3 - 50 well samples.

3.2.5 *Field Blanks* - 1 field blank should be collected at each well, but analyzed only if the well sample is positive.

## 4.0 AIR STUDY QC PROCEDURES

**4.1 Air Study Method Validation (trapping efficiency)** - In addition to the general procedures, the trapping efficiency should be determined. This normally involves collecting a series of 2-stage air samples. The top stage sampling tube contains glass-wool and is spiked. The bottom stage consists of the normal sampling tube. The 2-stage sample is placed on an air sampler and run for the appropriate amount of time. Both stages are then analyzed to determine the proportion of the spike trapped in the bottom stage. The test should consist of two to five replicate analyses at two to five spike levels. Samplers should run for various lengths of time, if necessary. To determine the precision of the spiking technique, five sample tubes with glass wool should be spiked and analyzed. Oxidation products should also be analyzed to determine the rate of conversion. Exact test specifications are chosen by the project leader.

**4.2 Air Study Continuing QC** - In addition to the general procedures, one reagent spike should be analyzed with each extraction set. The air sampling matrix will occasionally give an enhanced detector response.

In general, it is not possible to split air samples, so split matrix analyses are not usually done.

STANDARD OPERATING PROCEDURE  
*Chemistry Laboratory Quality Control*

---

## 5.0 CALCULATIONS

**5.1 Calculating the Method Detection Limit** - The MDL is determined by performing the following calculation:

$$\text{MDL} = t \times S$$

where:

t = Student's t value for 99% confidence level (1-tailed) and n-1 degrees of freedom

S = standard deviation

**5.2 Calculating Warning and Control Limits** - The method validation data are used to set warning and control limits. Warning limits will be established at the mean percent recovery plus/minus 1 - 2 times the standard deviation. Control limits will be established at the mean percent recovery plus/minus 2 - 3 times the standard deviation. Any subsequent spiked samples outside the control limits may require the set of samples associated with that spike to be reanalyzed.

## 6.0 REPORTING REQUIREMENTS

These reporting requirements pertain only to the QC data. There may be other reporting requirements specified in the EHAP Analytical Laboratory Specifications Form (Appendix 2).

**6.1 Reporting Method Development Results** - The following should be reported by the lab to the EHAP QA officer prior to the start of any field sample analyses: the spike level and concentration detected for each sample of the MDL determination, the method validation, and the storage stability. The EHAP QA officer will review, summarize and submit the data to the project leader.

**6.2 Reporting Continuing QC Results** - The following QC results should be reported by the lab to the EHAP QA officer on a continuous basis: the concentration of all blanks, the concentration detected for all spikes, the amount added for all spikes. Any spiked samples outside the control limits may require the set of samples associated with that spike to be reanalyzed. The EHAP QA officer will

STANDARD OPERATING PROCEDURE  
***Chemistry Laboratory Quality Control***

---

review, summarize and submit the data to the project leader. In addition, the project leader may request to be notified if any problems arise during the course of chemical analysis.

**6.3 Reporting Sample Results** - The laboratory should not use any spike or blank data to adjust the field sample results, unless specified by the project leader. Any adjustments should be made by EHAP personnel.

## **7.0 STUDY-SPECIFIC DECISIONS**

The project leader is responsible for the following specific decisions for each individual study. These decisions must be made for both the primary lab and the QC lab, if one is used. All decisions should be given to the EHAP QA officer who will document the decisions and transmit them to the lab using the EHAP Analytical Laboratory Specifications Form.

7.1 Method performance goals - reporting limit, specificity, precision, accuracy, sample size, time to complete analysis, etc.

7.2 Number of MDL spike samples

7.3 Method validation spike levels and number of replicates

7.4 Warning and control limit criteria (1 - 3X standard deviation)

7.5 Storage stability test design

7.6 Number or frequency of continuous QC spike analyses

7.7 Concentration of continuous QC spike samples

7.8 Number or frequency of analytical confirmation

7.9 Number or frequency of split analyses

7.10 Use, selection and concentration of an internal standard



**STANDARD OPERATING PROCEDURE**  
***Chemistry Laboratory Quality Control***

---

- 7.11 Number or frequency of replicate sample analyses
- 7.12 Number or frequency of blind spike analyses
- 7.13 Concentration of blind spike samples (also select analyte(s) if multi-residue method)
- 7.14 Number or frequency of replicate extract analyses
- 7.15 Number or frequency of split extract analyses
- 7.16 Number or frequency of standard reference material analyses
- 7.17 Method of AB 2021 verification - 2nd lab or 2nd method
- 7.18 Trapping efficiency test design
- 7.19 Number or frequency of reagent spike analyses

**8.0 REFERENCES**

California Department of Pesticide Regulation. 1988. Chemistry Laboratory Quality Control Guidelines. Environmental Hazards Assessment Program.

Segawa, R. 1993. AB 2021 Confirmation and Verification Policy. Memorandum to Kean Goh, dated November 22, 1993. Environmental Hazards Assessment Program.

**APPENDIX 1 - U.S. EPA Method Detection Limit Determination**

**APPENDIX 2 - Analytical Laboratory Specifications**

## APPENDIX 1

Environmental Protection Agency

Pt. 136, App. B

### APPENDIX B TO PART 136—DEFINITION AND PROCEDURE FOR THE DETERMI- NATION OF THE METHOD DETECTION LIMIT—REVISION 1.11

#### Definition

The method detection limit (MDL) is defined as the minimum concentration of a substance that can be measured and reported with 99% confidence that the analyte concentration is greater than zero and is determined from analysis of a sample in a given matrix containing the analyte.

#### Scope and Application

This procedure is designed for applicability to a wide variety of sample types ranging from reagent (blank) water containing analyte to wastewater containing analyte. The MDL for an analytical procedure may vary as a function of sample type. The procedure requires a complete, specific, and well defined analytical method. It is essential that all sample processing steps of the analytical method be included in the determination of the method detection limit.

The MDL obtained by this procedure is used to judge the significance of a single measurement of a future sample.

The MDL procedure was designed for applicability to a broad variety of physical and chemical methods. To accomplish this, the procedure was made device- or instrument-independent.

#### Procedure

1. Make an estimate of the detection limit using one of the following:

(a) The concentration value that corresponds to an instrument signal/noise in the range of 2.5 to 5.

(b) The concentration equivalent of three times the standard deviation of replicate instrumental measurements of the analyte in reagent water.

(c) That region of the standard curve where there is a significant change in sensitivity, i.e., a break in the slope of the standard curve.

(d) Instrumental limitations.

It is recognized that the experience of the analyst is important to this process. However, the analyst must include the above considerations in the initial estimate of the detection limit.

2. Prepare reagent (blank) water that is as free of analyte as possible. Reagent or interference free water is defined as a water sample in which analyte and interferent concentrations are not detected at the method detection limit of each analyte of interest. Interferences are defined as systematic errors in the measured analytical signal of an established procedure caused by

the presence of interfering species (interferent). The interferent concentration is presupposed to be normally distributed in representative samples of a given matrix.

3. (a) If the MDL is to be determined in reagent (blank) water, prepare a laboratory standard (analyte in reagent water) at a concentration which is at least equal to or in the same concentration range as the estimated method detection limit. (Recommend between 1 and 5 times the estimated method detection limit.) Proceed to Step 4.

(b) If the MDL is to be determined in another sample matrix, analyze the sample. If the measured level of the analyte is in the recommended range of one to five times the estimated detection limit, proceed to Step 4.

If the measured level of analyte is less than the estimated detection limit, add a known amount of analyte to bring the level of analyte between one and five times the estimated detection limit.

If the measured level of analyte is greater than five times the estimated detection limit, there are two options.

(1) Obtain another sample with a lower level of analyte in the same matrix if possible.

(2) The sample may be used as is for determining the method detection limit if the analyte level does not exceed 10 times the MDL of the analyte in reagent water. The variance of the analytical method changes as the analyte concentration increases from the MDL, hence the MDL determined under these circumstances may not truly reflect method variance at lower analyte concentrations.

4. (a) Take a minimum of seven aliquots of the sample to be used to calculate the method detection limit and process each through the entire analytical method. Make all computations according to the defined method with final results in the method reporting units. If a blank measurement is required to calculate the measured level of analyte, obtain a separate blank measurement for each sample aliquot analyzed. The average blank measurement is subtracted from the respective sample measurements.

(b) It may be economically and technically desirable to evaluate the estimated method detection limit before proceeding with 4a. This will: (1) Prevent repeating this entire procedure when the costs of analyses are high and (2) Insure that the procedure is being conducted at the correct concentration. It is quite possible that an inflated MDL will be calculated from data obtained at many times the real MDL even though the level of analyte is less than five times the calculated method detection limit. To insure that the estimate of the method detection limit is a good estimate, it is necessary to determine that a lower concentration of analyte will not result in a signifi-

cantly lower method detection limit. Take two aliquots of the sample to be used to calculate the method detection limit and process each through the entire method, including blank measurements as described above in 4a. Evaluate these data:

(1) If these measurements indicate the sample is in desirable range for determination of the MDL, take five additional aliquots and proceed. Use all seven measurements for calculation of the MDL.

(2) If these measurements indicate the sample is not in correct range, reestimate the MDL, obtain new sample as in 3 and repeat either 4a or 4b.

5. Calculate the variance ( $S^2$ ) and standard deviation ( $S$ ) of the replicate measurements, as follows:

$$S^2 = \frac{1}{n-1} \left[ \sum_{i=1}^n X_i^2 - \left( \sum_{i=1}^n X_i \right)^2 / n \right]$$

$$S = (S^2)^{1/2}$$

where:

$X_i$ ;  $i=1$  to  $n$ , are the analytical results in the final method reporting units obtained from the  $n$  sample aliquots and  $\Sigma$  refers to the sum of the  $X$  values from  $i=1$  to  $n$ .

6. (a) Compute the MDL as follows:

$$\text{MDL} = t_{(n-1), 0.99} (S)$$

where:

MDL = the method detection limit

$t_{(n-1), 0.99}$  = the students'  $t$  value appropriate for a 99% confidence level and a standard deviation estimate with  $n-1$  degrees of freedom. See Table.

$S$  = standard deviation of the replicate analyses.

(b) The 95% confidence interval estimates for the MDL derived in 6a are computed according to the following equations derived from percentiles of the chi square over degrees of freedom distribution ( $\chi^2/df$ ).

$$\text{LCL} = 0.64 \text{ MDL}$$

$$\text{UCL} = 2.20 \text{ MDL}$$

where: LCL and UCL are the lower and upper 95% confidence limits respectively based on seven aliquots.

7. Optional iterative procedure to verify the reasonableness of the estimate of the MDL and subsequent MDL determinations.

(a) If this is the initial attempt to compute MDL based on the estimate of MDL formulated in Step 1, take the MDL as calculated in Step 6, spike the matrix at this calculated MDL and proceed through the procedure starting with Step 4.

(b) If this is the second or later iteration of the MDL calculation, use  $S^2$  from the current MDL calculation and  $S^2$  from the previous MDL calculation to compute the F-

ratio. The F-ratio is calculated by substituting the larger  $S^2$  into the numerator  $S_1^2$  and the other into the denominator  $S_2^2$ . The computed F-ratio is then compared with the F-ratio found in the table which is 3.05 as follows: if  $S_1^2/S_2^2 < 3.05$ , then compute the pooled standard deviation by the following equation:

$$S_{\text{pooled}} = \left[ \frac{6S_1^2 + 6S_2^2}{12} \right]^{1/2}$$

If  $S_1^2/S_2^2 > 3.05$ , respike at the most recent calculated MDL and process the samples through the procedure starting with Step 4. If the most recent calculated MDL does not permit qualitative identification when samples are spiked at that level, report the MDL as a concentration between the current and previous MDL which permits qualitative identification.

(c) Use the  $S_{\text{pooled}}$  as calculated in 7b to compute the final MDL according to the following equation:

$$\text{MDL} = 2.681 (S_{\text{pooled}})$$

where 2.681 is equal to  $t_{(12), 0.99}$ .

(d) The 95% confidence limits for MDL derived in 7c are computed according to the following equations derived from percentiles of the chi squared over degrees of freedom distribution.

$$\text{LCL} = 0.72 \text{ MDL}$$

$$\text{UCL} = 1.65 \text{ MDL}$$

where LCL and UCL are the lower and upper 95% confidence limits respectively based on 14 aliquots.

TABLES OF STUDENTS'  $t$  VALUES AT THE 99 PERCENT CONFIDENCE LEVEL

Number of replicates	Degrees of freedom (n-1)	$t_{(n-1), 0.99}$
7	6	3.143
8	7	2.998
9	8	2.896
10	9	2.821
11	10	2.764
16	15	2.602
21	20	2.528
26	25	2.485
31	30	2.457
61	60	2.390
60	60	2.326

#### Reporting

The analytical method used must be specifically identified by number or title and the MDL for each analyte expressed in the appropriate method reporting units. If the analytical method permits options which

affect the method detection limit, these conditions must be specified with the MDL value. The sample matrix used to determine the MDL must also be identified with MDL value. Report the mean analyte level with the MDL and indicate if the MDL procedure was iterated. If a laboratory standard or a sample that contained a known amount analyte was used for this determination, also report the mean recovery.

If the level of analyte in the sample was below the determined MDL or exceeds 10 times the MDL of the analyte in reagent water, do not report a value for the MDL.

[49 FR 43430, Oct. 26, 1984; 50 FR 694, 696, Jan. 4, 1985, as amended at 51 FR 23703, June 30, 1986]

#### APPENDIX C TO PART 136—INDUCTIVELY COUPLED PLASMA—ATOMIC EMISSION SPECTROMETRIC METHOD FOR TRACE ELEMENT ANALYSIS OF WATER AND WASTES METHOD 200.7

##### 1. Scope and Application

1.1 This method may be used for the determination of dissolved, suspended, or total elements in drinking water, surface water, and domestic and industrial wastewaters.

1.2 Dissolved elements are determined in filtered and acidified samples. Appropriate steps must be taken in all analyses to ensure that potential interferences are taken into account. This is especially true when dissolved solids exceed 1500 mg/L. (See Section 5.)

1.3 Total elements are determined after appropriate digestion procedures are performed. Since digestion techniques increase the dissolved solids content of the samples, appropriate steps must be taken to correct for potential interference effects. (See Section 5.)

1.4 Table 1 lists elements for which this method applies along with recommended wavelengths and typical estimated instrumental detection limits using conventional pneumatic nebulization. Actual working detection limits are sample dependent and as the sample matrix varies, these concentrations may also vary. In time, other elements may be added as more information becomes available and as required.

1.5 Because of the differences between various makes and models of satisfactory instruments, no detailed instrumental operating instructions can be provided. Instead, the analyst is referred to the instruction provided by the manufacturer of the particular instrument.

##### 2. Summary of Method

2.1 The method describes a technique for the simultaneous or sequential multielement

determination of trace elements in solution. The basis of the method is the measurement of atomic emission by an optical spectroscopic technique. Samples are nebulized and the aerosol that is produced is transported to the plasma torch where excitation occurs. Characteristic atomic-line emission spectra are produced by a radio-frequency inductively coupled plasma (ICP). The spectra are dispersed by a grating spectrometer and the intensities of the lines are monitored by photomultiplier tubes. The photocurrents from the photomultiplier tubes are processed and controlled by a computer system. A background correction technique is required to compensate for variable background contribution to the determination of trace elements. Background must be measured adjacent to analyte lines on samples during analysis. The position selected for the background intensity measurement, on either or both sides of the analytical line, will be determined by the complexity of the spectrum adjacent to the analyte line. The position used must be free of spectral interference and reflect the same change in background intensity as occurs at the analyte wavelength measured. Background correction is not required in cases of line broadening where a background correction measurement would actually degrade the analytical result. The possibility of additional interferences named in 5.1 (and tests for their presence as described in 5.2) should also be recognized and appropriate corrections made.

##### 3. Definitions

3.1 *Dissolved*—Those elements which will pass through a 0.45  $\mu\text{m}$  membrane filter.

3.2 *Suspended*—Those elements which are retained by a 0.45  $\mu\text{m}$  membrane filter.

3.3 *Total*—The concentration determined on an unfiltered sample following vigorous digestion (Section 9.3), or the sum of the dissolved plus suspended concentrations. (Section 9.1 plus 9.2).

3.4 *Total recoverable*—The concentration determined on an unfiltered sample following treatment with hot, dilute mineral acid (Section 9.4).

3.5 *Instrumental detection limit*—The concentration equivalent to a signal, due to the analyte, which is equal to three times the standard deviation of a series of ten replicate measurements of a reagent blank signal at the same wavelength.

3.6 *Sensitivity*—The slope of the analytical curve, i.e. functional relationship between emission intensity and concentration.

3.7 *Instrument check standard*—A multielement standard of known concentrations prepared by the analyst to monitor and verify instrument performance on a daily basis. (See 7.8.1)

CALIFORNIA DEPARTMENT OF PESTICIDE REGULATION  
ENVIRONMENTAL HAZARDS ASSESSMENT PROGRAM  
ANALYTICAL LABORATORY SPECIFICATIONS

Project No. \_\_\_\_\_  
Lab Project Manager \_\_\_\_\_  
Project Chemist \_\_\_\_\_  
EHAP Project Manager \_\_\_\_\_  
EHAP Lab Liaison/ QA Officer Nancy Miller

Lab \_\_\_\_\_  
Phone \_\_\_\_\_  
Phone \_\_\_\_\_  
Phone \_\_\_\_\_  
Phone 322-3082

Type of Analysis:

Sample Type	Analysis For	Reporting Limit	Number of Samples
1			
2			
3			
4			

Methods Development: See attachment  
Sample Storage: \_\_\_\_\_  
Sample Storage: \_\_\_\_\_  
Sample Extraction: \_\_\_\_\_  
Analytical Standard Source: \_\_\_\_\_  
Instrumentation: \_\_\_\_\_  
Confirmation Method: \_\_\_\_\_  
Continuing QC: See attachment  
Sample Disposition: \_\_\_\_\_  
Extract Disposition: \_\_\_\_\_  
Reporting/Turnaround: See attachment  
Cost of Analysis: See attachment

Other Specifications:

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Approved by: Nancy Miller  
CDPR Representative

\_\_\_\_\_  
Lab Representative

\_\_\_\_\_  
Date

CALIFORNIA DEPARTMENT OF PESTICIDE REGULATION  
ENVIRONMENTAL HAZARDS ASSESSMENT PROGRAM  
ANALYTICAL LABORATORY SPECIFICATIONS

METHODS DEVELOPMENT AND VALIDATION

**Specifications**

**Validation\***

Method # \_\_\_\_\_  
Sample Matrix: \_\_\_\_\_  
Analyzed For: \_\_\_\_\_  
Reporting Limit: \_\_\_\_\_  
Other Specifications: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

**Sample Type**

**Spike Level**

**# Reps**

1  
2  
3  
4  
5

Method # \_\_\_\_\_  
Sample Matrix: \_\_\_\_\_  
Analyzed For: \_\_\_\_\_  
Reporting Limit: \_\_\_\_\_  
Other Specifications: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

**Sample Type**

**Spike Level**

**# Reps**

1  
2  
3  
4  
5

Method # \_\_\_\_\_  
Sample Matrix: \_\_\_\_\_  
Analyzed For: \_\_\_\_\_  
Reporting Limit: \_\_\_\_\_  
Other Specifications: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

**Sample Type**

**Spike Level**

**# Reps**

1  
2  
3  
4  
5

\* Each laboratory shall determine a method detection limit (MDL), instrument detection limit (IDL) and a reporting limit (RL) for each analyte. Each laboratory shall also document their terms, definitions and procedures for determining MDL, IDL and RL in their approved analytical method. Each laboratory shall provide a copy of their approved analytical method before analyzing any field samples. The results from the method validation study will be used to establish recovery control limits for the field study.

CALIFORNIA DEPARTMENT OF PESTICIDE REGULATION  
ENVIRONMENTAL HAZARDS ASSESSMENT PROGRAM  
ANALYTICAL LABORATORY SPECIFICATIONS

METHODS DEVELOPMENT

**Specifications**

**Validation\***

Method # \_\_\_\_\_  
Sample Matrix: \_\_\_\_\_  
Analyzed For: \_\_\_\_\_  
Reporting Limit: \_\_\_\_\_  
Other Specifications: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Sample Type	Spike Level	# Reps
1		
2		
3		
4		
5		

Method # \_\_\_\_\_  
Sample Matrix: \_\_\_\_\_  
Analyzed For: \_\_\_\_\_  
Reporting Limit: \_\_\_\_\_  
Other Specifications: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Sample Type	Spike Level	# Reps
1		
2		
3		
4		
5		

Method # \_\_\_\_\_  
Sample Matrix: \_\_\_\_\_  
Analyzed For: \_\_\_\_\_  
Reporting Limit: \_\_\_\_\_  
Other Specifications: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Sample Type	Spike Level	# Reps
1		
2		
3		
4		
5		

\* The results from the method validation study will be used to establish recovery control limits for the field study.  
A full description of the analytical method should be included with the results of the method validation study.

CALIFORNIA DEPARTMENT OF PESTICIDE REGULATION  
ENVIRONMENTAL HAZARDS ASSESSMENT PROGRAM  
ANALYTICAL LABORATORY SPECIFICATIONS

CONTINUING QUALITY CONTROL

Reagent or Solvent Blanks

Reagent or Solvent Spikes

Blank-Matrix Spikes

Matrix

Spike Level

Matrix

Spike Level

Matrix

Spike Level

Matrix

Spike Level

Actual Matrix Spikes

Replicate Matrix Analyses

Replicate Extract Injections

Confirmation Analyses

or Well Samples:

Primary Samples

Backup Samples

Field Blank Samples

Storage Dissipation Study



## BUDGET

### Cost

Attn: Nancy Miller

## **SUPPLEMENT 7**


**STANDARD OPERATING PROCEDURE**  
**Procedure for Generating Rinse Blanks**

---

**KEY WORDS-**


Rinse; decontamination; splitter

**APPROVALS**

APPROVED BY:  DATE: 6/25/98  
Management

APPROVED BY:  DATE: 6/24/98  
EHAP Senior Scientist

APPROVED BY:  DATE: 6/23/98  
EHAP Quality Assurance Officer

PREPARED BY:  DATE: 6/23/98

Environmental Hazards Assessment Program (EHAP) organization and personnel such as management, senior scientist, quality assurance officer, project leader, etc. are defined and discussed in SOP ADMN002.

## **STANDARD OPERATING PROCEDURE**

### **Procedure for Generating Rinse Blanks**

---

## **1.0 INTRODUCTION**

### **1.1 Purpose**

Rinse blanks are created to assess the efficacy of equipment decontamination procedures described in SOPs FSWA004 and FSWA005.

### **1.2 Scope**

This document will provide specific instructions for collecting rinse blanks from surface water sampling equipment and/or the water splitting equipment.

## **2.0 MATERIALS**

- 2.1** Deionized water (sufficient to fill sample bottles)
- 2.2** Sample bottles (same number used for surface water analysis)
- 2.3** Clean Geotech® Dekaport port splitter
- 2.4** All containers used to collect or contain samples: e.g. Teflon® bottle, Teflon® spout, stainless steel buckets, milkcan, funnels
- 2.5** Chain of Custody records
- 2.6** Latex disposable gloves
- 2.7** Level

## **3.0 PROCEDURES**

Rinse Blanks should be performed at least once every study or after each sample that represents 10% of the total number of samples collected in the study, whichever is more. Enough rinse blanks should be generated to analyze all chemicals analyzed for in a particular study. Rinse blanks should be collected from both sampling and splitting equipment, or both combined if all the equipment is cleaned and split at one location. Below is an example describing the procedure used for generating rinse blanks when both sampling and splitting equipment are used at one location.

### **3.1 Instructions for Generating Rinse Blanks**

- 3.1.1** After the samples have been collected at the sampling site and the equipment listed in 2.3 and 2.4 above have been completely decontaminated according to SOP#s FSWA004 and FSWA005, the rinse blank may be collected.
-

**STANDARD OPERATING PROCEDURE**  
**Procedure for Generating Rinse Blanks**

---

**3.1.2** Place the cleaned Geotech® Dekaport water splitter on level ground. Make sure all splitter water spouts are level to ensure a fairly even water flow. Place a level across the top of the splitter to ensure that it is level.

**3.1.3** While wearing disposable gloves, set up the same number of sample bottles as used for surface water analysis, following instructions for splitting procedures in FSWA004.

**3.1.4** Pour about 500ml more deionized water than required to fill the rinse blank sample bottles into the first piece of sampling equipment (e.g. Teflon® bottle). Swirl the water around and then pour the water into the next piece of sampling equipment (e.g. the milkcan).

**3.1.5** Continue to pour the water and swirl until the water has rinsed all the sampling equipment. Prior to completely pouring the remainder of the sample water out of the sampling containers swirl the water one last time to ensure that any residual sediment stays with the sample water and not at the bottom or along the sides of the container. Lastly, pour the deionized water through the Dekaport splitter and fill the rinse blank sample bottles. If there are extra splitter spouts, put a clean bucket under the spouts. Pour the water from this bucket back through the splitter. Continue the process until all the bottles are full.

**3.1.6** Cap all bottles and prepare COCs in the same manner as surface water samples. Add the words "Rinse Blank" to the comments section of the Check-In Sheet. If samples need to be acidified, add three drops of 3N HCL. Store samples at 4°C.

**3.1.7** Cover all containers and the splitter with clean plastic bags.

## **SUPPLEMENT 8**

California Department of Pesticide Regulation  
Environmental Hazards Assessment Program  
1020 N Street  
Sacramento, California 95814

SOPNumber:ADMN005.00  
Previous SOP:none  
Page 1 of 5

**STANDARD OPERATING PROCEDURE**  
**Archiving Study Data, Records, and Other Documents**

---

**KEY WORDS**

archivist; quality assurance; SOP; project leader; check-in; check-out; GLP

**APPROVALS**

APPROVED BY: John L. Sanders DATE: 3/6/97  
Management

APPROVED BY: H. L. Brown DATE: 3-5-97  
EHAP Senior Scientist

APPROVED BY: Randy Segura DATE: 2-26-97  
EHAP Quality Assurance Officer

PREPARED BY: [Signature] DATE: 2-24-97

Environmental Hazards Assessment Program (EHAP) organization and personnel such as management, senior scientist, quality assurance officer, project leader, etc. are defined and discussed in SOP ADMN002.

**STANDARD OPERATING PROCEDURE**  
**Archiving Study Data, Records, and Other Documents**

---

**1.0 INTRODUCTION**

**1.1 Purpose**

This Standard Operating Procedure (SOP) describes the archiving procedures for all records and data associated with studies conducted by the Environmental Hazards Assessment Program (EHAP), Department of Pesticide Regulation, California Environmental Protection Agency. This SOP should be followed for the archiving of all study data.

**1.2 Definitions**

**Archivist** is the individual responsible for maintaining the archives.

**Project leader** is the individual responsible for the overall conduct of a study.

**Study file** is the file containing all of the records and data for a study.

**Study number** is the unique identification number assigned to each study.

**2.0 MATERIALS**

none

**3.0 PROCEDURES**

**3.1** Archived study files shall consist of all raw data, field notes, protocols, interim reports, and a master copy of the final report. Correspondence and other documents relating to interpretation and evaluation of data must also be included in the study file if they are not included in the final report. Raw data results will in most cases consist of the original chain of custody with the analytical result and chemist signature (white copy).

**3.2** Study files will be retained by the project leader until the final report is approved. At that point, the project leader will give the study file to the archivist. During the period between initiation of the study and final report approval, the archivist will include the location of the study file in the archives index.

---



**STANDARD OPERATING PROCEDURE**  
**Archiving Study Data, Records, and Other Documents**

---

3.3 Archiving of study files must be done only by the archivist. The project leader must organize the study file so that information is readily retrievable from within the file.

3.4 The project leader shall provide the archivist with an electronic copy of the final report. For studies conducted under Good Laboratory Practices, additional requirements will apply (U.S. EPA, 1992), including the following:

3.4.1 Photocopied material shall not be included in the study file.

3.4.2 All field notes, data records, etc. must be in ink.

3.5 The archivist shall be the only individual with access to the archives. The archivist will designate an alternate when he/she is absent.

3.6 The study files shall be filed numerically by study number. The project leader must request a study number prior to the beginning of the study. Each protocol must have a study number for approval.

3.7 An index of the archived study files shall be kept by the archivist. Other individuals may have copies of this index upon request.

3.7.1 The index shall list the study files numerically by study number.

3.7.2 Each entry on the index shall list the study number, the date the study file was archived, and the title of the study.

3.7.3 The index shall list the location of files for studies still in progress, as stated in section 3.2

3.8 Requests for information contained in archived files will be made to the archivist. Check-in/out procedures are as follows:

3.8.1 Archivist retrieves study file.

3.8.2 The study file number is recorded on the check-in/out log. The check-out date will be recorded, and the archivist and requestor will initial it.

3.8.3 No alterations or additions shall be made to the files while in the borrower's

**STANDARD OPERATING PROCEDURE**  
**Archiving Study Data, Records, and Other Documents**

---

possession.

3.8.4 The study file shall be returned to the archivist by the same individual who checked it out. The file shall be returned in the same organized manner as it was checked out. The check-in date will be recorded in the log and the archivist and the borrower shall initial it.

3.8.5 The archivist is responsible for refiling the study file in the archives.

3.9 A check-in/check-out log will be kept by the archivist. This log shall contain the following information:

3.9.1 The study number.

3.9.2 The name of the borrower.

3.9.3 The check-out date.

3.9.4 The check-in date.

3.9.5 Spaces for the archivist and borrower to initial both the check-in and check-out dates.

3.10 Electronic copies of final reports will be stored indefinitely in a manner that prevents deterioration and insures that copies are easily accessible by the archivist. It is the responsibility of the archivist to manage these files, updating electronic format when appropriate. When updates are necessary, the archivist will state the type of change on the archive index, initial, and date the entry.

3.11 Study files will be retained for a minimum of five years. After that time, the archivist may continue storage of files, or transfer to another location. In all cases, study file transfers or disposals will be noted in the archives index.

California Department of Pesticide Regulation  
Environmental Hazards Assessment Program  
1020 N Street  
Sacramento, California 95814

SOPNumber:ADMN005.00  
Previous SOP:none  
Page 5 of 5

**STANDARD OPERATING PROCEDURE**  
**Archiving Study Data, Records, and Other Documents**

---

**4.0 REFERENCES**

U.S. Environmental Protection Agency. 1989. Federal Insecticide Fungicide, and Rodenticide Act (FIFRA); Good Laboratory Practice Standards; Final Rule.

U.S. Environmental Protection Agency. 1992. Federal Insecticide Fungicide, and Rodenticide Act (FIFRA) Good Laboratory Practice Standards (GLPS) Questions and Answers. Office of Prevention, Pesticides, and Toxic Substances.