

California Department of Pesticide Regulation  
Environmental Hazards Assessment Program  
1020 N Street  
Sacramento, CA 95814

SOP Number: QAQC003.00  
Previous SOP: none  
Page 1 of 7

STANDARD OPERATING PROCEDURE  
**Sample Tracking Procedures**

---

**KEY WORDS**

Sample Tracking, Sample Tracking Database, Chain-of custody, Sample

**APPROVALS**

APPROVED BY: John S. Sanders DATE: 3/6/97  
Management

APPROVED BY: H. L. Br... DATE: 3-5-97  
EHAP Senior Scientist

APPROVED BY: Randa Seamus DATE: 2-26-97  
EHAP Quality Assurance Officer

PREPARED BY: Andrea Hoffman DATE: 2-26-97

## STANDARD OPERATING PROCEDURE

### Sample Tracking Procedures

---

## 1.0 INTRODUCTION

### 1.1 Purpose

This Standard Operating Procedure (SOP) discusses sample check-in and check-out procedures; the recording of chemistry data; sample disposal procedures; and the Sample Tracking Database.

### 1.2 Definitions

A **sample** is any environmental substance collected and analyzed for chemical content.

**Chain-of-custody** is a record describing in detail all pertinent information specific to each sample, including dates and signatures of persons handling the sample.

**Sample Tracking Database** is a relational database designed in Microsoft Access to trace a sample from the time it is checked into the storage facility until the sample is submitted to a laboratory for analysis or disposed of after a study is completed.

## 2.0 SAMPLE TRACKING

### 2.1 Sample Tracking Codes

Sample tracking codes are abbreviations for fields in the database that refer to specific information about each sample. The study number in combination with the sample number is identified as the key field and all information specific to the sample is referenced by the following codes back to the key field.

#### **SAMPLE CODES:**

P= Primary	R= Replicate	B= Backup	FB= Field Blank
* = Split	S= Spike	BG= Background	BM= Blank Matrix
A= Acidified	U= Unacidified	RB= Rinse Blank	

## STANDARD OPERATING PROCEDURE

### Sample Tracking Procedures

---

**STORAGE LOCATION CODES** refer to the storage location of each sample at the storage facility.

F= Fresno	R= Refrigerator	SRI 0= Sacramento Refrigerator #1 0
R= Riverside	F= Freezer	SFO7= Sacramento Freezer #07
S= Sacramento	A= Air Temp.	D= Deep Freeze
W= Warehouse	L= Lab	

**SAMPLE TYPE CODES** refer to the sample matrix collected.

FRU= Fruit	DVEG= Dislodgeable Vegetation	TWG= Twigs
SOI= Soil	SSS= Stainless Steel Sheets	EXT= Extract
WAT= Water	LOV= Lo-Vol	STD= Standard
VEG= Vegetation	HIV= Hi-Vol	SUR= Surrogate
SED= Sediment	FILT= Filtrate	TUR= Turf
TAN= Tank	KIM= Kimbie	SAN= Sand
AIR= Air	TRP= Air Cassettes	BRA= Branch

**SAMPLE CONTAINER CODES** refer to the type of container each sample is placed in during storage.

QMSJ= Quart Mason Jar	1 LAMBR= 1 Liter Amber Bottle
PMSJ= Pint Mason Jar	HPMSJR= Half Pint Mason Jar
PBAG= Plastic Bag	HIVJAR= Hi-Vol Jar
FOIL= Aluminum Sheets	P500mL= Plastic Bottle (500 mL)
CAS= Air Cassettes	1 LPC= 1 Liter Polycarb. Bottle
ILPP= 1 Liter Polyprop. Container	VIAL= Small Standard Vial

500mLPC= 500mL Polycarb. Container  
250mLAMBR= 250mL Amber Bottle  
500mLAMBR= 500mL Amber Bottle  
500mLHDPP= 500mL High Density Polyprop.

## STANDARD OPERATING PROCEDURE

### Sample Tracking Procedures

---

**LABORATORY CODES** refer to the specific laboratory each sample is shipped to for analysis.

QUAN= Quanterra Laboratory  
ATL= Aquatic Toxicology Lab  
FMC= FMC Corporation  
ZEN= Zeneca Ag Products  
APPL= Ag and Priority Pollut Labs  
NCL= North Coast Labs  
FRES= Fresno Soils Lab

CDFA= CA Dept. of Food & Agr.  
CDFG= CA Dept. of Fish & Game  
ALTA= ALTA Analytical Laboratory  
VAL= Valent Dublin Laboratory  
MOR= Morse Laboratories Inc.  
UCD= University California Davis  
WSAC= W. Sacramento Soils Lab

**ANALYSIS TYPE** refers to the type of test method to be performed on each sample.

C= Chemical  
O= Organic  
T= Texture

F= Tracer  
P= pH  
B= Bulk Density

E= Elisa  
M= Moisture  
V= Various

## 2.2 Sample Check-in Procedures

All samples received at the storage facility are immediately put in a refrigerator or freezer depending on the matrix specific storage requirements. The field crew fills out a two-part check-in sheet (Figure A) using the sample tracking codes listed in section 2.1.

## STANDARD OPERATING PROCEDURE

### Sample Tracking Procedures

---

The check-in sheet must be complete in order to properly track environmental samples. The following is a description of each key component of the check-in sheet.

**Project ID:** The study number or name.

**Date Received:** The date the sample was received from the field crew.

**Checked-in by:** The initials of the person who fills out the check-in sheet.

**Remarks:** List any additional or necessary information regarding the samples listed on the check-in sheet.

**EHAP Sample No.:** The number assigned to a labeled sampling container.

**Sample Code:** List sample code (Section 2.1 for codes).

**Date Sample Collected:** Note the sample collection date.

**Sample Type:** Specify the type of sample collected (Section 2.1).

**Container Type:** What the sample is stored in (Section 2.1).

**Analysis Type:** The type of analysis the sample is intended for (Section 2.1).

**Analysis:** List the type of chemical the sample is to be analyzed for.

**Comment:** Space provided for additional information regarding individual samples.

**Date/Logged in by:** The date and person who enters information into the Sample Tracking Database.

**Storage Location:** List where the sample is being stored (Section 2.1).

After the check-in sheet is completed, each field sample is compared against its corresponding chain-of-custody (COC), then signed and dated by the sample custodian receiving the sample. The white and yellow copies of the each COC is removed and sent with its corresponding field sample to the laboratory. The pink copy is used to enter the information into the Sample Tracking Database. The pink copy is then sent to the Project Leader. Any remaining samples held at the storage facility are stored under their required storage conditions with the white and yellow copies of their corresponding COC's.

## STANDARD OPERATING PROCEDURE

### Sample Tracking Procedures

---

#### 2.3 Sample Check-out Procedures

A two-part check-out sheet is filled out for any sample leaving the storage facility (Figure B). The check-out sheet must be complete in order to properly track environmental samples leaving the storage facility.

The check-out sheet is similar to the check-in sheet but differs in three components.

**Date Delivered:** The date the sample is taken to the laboratory.

**Checked-out by:** The initials of the person filling out and transporting the sample to the laboratory.

**Laboratory Delivering to:** Specify the destination code for the sample scheduled for analysis (Section 2.1).

A pink copy of the check-out sheet, and white and yellow copy of each COC are sealed in a plastic bag and accompany samples transported to the laboratory. The samples are then placed in ice chests and cooled to their required temperatures using blue ice, wet ice or dry ice. Ice chests are sealed with tape and labelled with the date and initials of the sample custodian using a permanent black marker. The white copy of the check-out sheet is retained by the QA/QC officer and is also used to enter information into the Sample Tracking Database.

#### 2.4 Chemistry Results

After results are received from the laboratory, the laboratory sample number, extraction and analysis date for each sample are entered into the Sample Tracking Database using the appropriate Microsoft Access query.

## STANDARD OPERATING PROCEDURE

### **Sample Tracking Procedures**

---

#### **2.5 Sample Disposal**

After each study is completed and with the approval of the Project Leader, all remaining samples stored in the storage facility may be disposed of by the sample custodian. A two-part Sample Disposal Sheet is completed and includes information similar to the check-out sheet (Figure C). This information is then entered into the Sample Tracking Database using the appropriate Microsoft Access query. The white copy of the Sample Disposal Sheet is retained by the QA/QC officer while the yellow copy is used to enter the information into the database.

#### **3.0 Sample Tracking Database**

All the information reported on the check-in, check-out, chemistry result, and sample disposal sheets is entered in the Sample Tracking Database using tables in Microsoft Access. Queries, forms and reports are designed specifically for each study to access fields for summarizing data.

#### **3.1 Computer Generated Backups**

Daily and weekly backups are conducted using Norton software and a tape drive. Diskettes are also used as a source for daily backup of individual study files.

DEPARTMENT OF PESTICIDE REGULATION

SAMPLE CHECK-IN SHEET  
30-007 (4/90)

Project ID (Study no.): \_\_\_\_\_

Logged in by: \_\_\_\_\_  
(key data entry person)

Date Received: \_\_\_\_\_

Storage location: \_\_\_\_\_  
(see # on outside of storage)

Checked- in by : \_\_\_\_\_

Remarks:

EHAP Sample No.	Sample Code	Date Sample Collected	Sample Type	Container Type	Analysis Type	Analysis Comment
--------------------	----------------	--------------------------	----------------	-------------------	------------------	---------------------

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins or other markings on the paper.



DEPARTMENT OF PESTICIDE REGULATION

SACRAMENTO SOILS LABORATORY  
3971 COMMERCE DRIVE, SUITE D  
WEST SACRAMENTO, CA 95691  
(916) 322-3082

**SAMPLE CHECK-OUT SHEET**  
**30- 008 (4/90)**

Today's Date: \_\_\_\_\_

Project ID (Study no.): \_\_\_\_\_

Logged out by: \_\_\_\_\_  
(key data entry person)

Date Delivered: \_\_\_\_\_

Storage location: \_\_\_\_\_  
(see # on outside of storage)

Checked-out by: \_\_\_\_\_

Laboratory Delivering to: \_\_\_\_\_

Remarks:

EHAP Sample No.	Sample Code	Date Sample Collected	Sample Type	Container Type	Analysis Type	Analysis	Comment
--------------------	----------------	--------------------------	----------------	-------------------	------------------	----------	---------

Today's Date: \_\_\_\_\_

EHAP Sample #	Sample Code	EHAP Sample #	Sample Code	EHAP Sample #	Sample Code	EHAP Sample #	Sample Code
------------------	----------------	------------------	----------------	------------------	----------------	------------------	----------------