SOP Number: FSWA001.00 Previous SOP: None

Page 1 of 9

STANDARD OPERATING PROCEDURE

Well Sampling: Obtaining Permission to Sample, Purging, Collection, Preservation, Storage, and Documentation

KEY WORDS

Permission to sample, Purging, Collection, Preservation, Storage, Documentation

APPROVALS		
APPROVED BY:_	Thanking goh	DATE: 12/30/98
APPROVED BY:_	Management	DATE: 12/29/98
APPROVED BY:	EHAP Senior Scientist	/ 7 DATE: 12/29/98
APPROVED D1	EHAP Quality Assurance Officer	DATE: 12/27/10
PREPARED BY:_	Joe Marade	DATE: 12/22/98
	0. Marade	

Page 2 of 9

SOP Number: FSWA001.00

Previous SOP: None

STANDARD OPERATING PROCEDURE

Well Sampling: Obtaining Permission to Sample, Purging, Collection, Preservation, Storage, and Documentation

1.0 INTRODUCTION

1.1 Purpose

To provide instruction for obtaining permission to sample a well, assessing its suitability for sampling, and the purging and collecting of a water sample from a well.

1.2 Definitions

1.2.1 **Purging** eliminates standing water from a well and allows the system to be recharged with water from the aquifer.

2.0 Materials

- 2.1 DPR Permission form to sample well
- 2.2 Plastic bag (18 inch by 24 inch) for ground cover
- 2.3 Plastic bag (6 inch by 12 inch) to cover electrical points
- 2.4 Core stem remover
- 2.5 Schrader® sampling tube
- 2.6 Locking pliers
- 2.7 Sample container (Refer to SOP QAQC005.00)
- 2.8 De-ionized water
- 2.9 Styrofoam holders for one-liter sample bottles or appropriate packing for other size containers
- 2.10 One-half pint mason jar
- 2.11 Portable pH meter
- 2.12 Preservative, if necessary (Refer to Study Specific Decision Section)
- 2.13 Replacement Schrader® valves
- 2.14 Replacement valve core stems
- 2.15 Teflon® tape
- 2.16 Ice chests
- 2.17 Thermometer for ice chests
- 2.18 Ice materials (Refer to Study Specific Decision Section)

SOP Number: FSWA001.00 Previous SOP: None

Page 3 of 9

STANDARD OPERATING PROCEDURE

Well Sampling: Obtaining Permission to Sample, Purging, Collection, Preservation, Storage, and Documentation

- 2.19 Chain of custody form
- 2.20 DWR form 429
- 2.21 Well information sheet
- 2.22 Polaroid camera
- 2.23 Polaroid film

3.0 PROCEDURES

3.1 Obtain Permission To Sample Well

- 3.1.1 Introduce yourself, explain project, determine who is well owner, and ask well owner to sign permission form to sample their well (Appendix I).
- 3.1.2 Obtain mailing information and if possible, any information regarding the last name of the original well owner and the year the well was drilled, well depth (drilled and standing water), depth to the first perforations in the well casing, previous well sample results, and the proximity of any other wells (if any) on the property.

3.2 Examine Well and Determine If Suitable For Sampling

- 3.2.1 Determine sample port. Sample ports include Schrader® valves, faucets, or petcocks. Every effort should be made to sample water prior to having it enter the storage tank. The airspace and increased temperatures inside a storage tank could accelerate dissipation or degradation of many pesticides.
- 3.2.2. Review well condition (look at casing, cap, pad), surrounding well location (soil type, cracks in soil, slope of land, depressions), presence and use of pesticides, type of well, pump type, and sample port, or anything unusual.
- 3.2.3 Accept or reject well based on well condition and location of sample port (See SOP FSWA006).

SOP Number: FSWA001.00

Previous SOP: None

Page 4 of 9

STANDARD OPERATING PROCEDURE

Well Sampling: Obtaining Permission to Sample, Purging, Collection, Preservation, Storage, and Documentation

3.3 Purging Procedure

- 3.3.1 Examine system and determine system layout.
- 3.3.2 Open enough faucets to allow the well pump to run a minimum of 10 minutes.
- 3.3.3 During the purging process, open enough hose bibs around the house to ensure that the pressure gauge on the storage tank holds at a steady level below the pump's shutoff pressure such that the pump output rate is equal to the system's drain rate.

3.4 Sampling Procedure

3.4.1 Schrader® valve sample ports refer to Procedure 3.5. Faucet and petcock sample ports refer to Procedure 3.6.

3.5 Preparing Schrader® Valve Sample Ports For Sample Collection

- 3.5.1 After running the pump for the desired time, turn faucets off and turn off power at the circuit box or switch box.
- 3.5.2 Cover the electrical point box with a plastic bag and secure with duct tape to avoid getting water in the points and short circuiting the system.
- 3.5.3 Remove the core stem from the Schrader® valve using a core stem remover.
- 3.5.4 Attach a Schrader® sampling tube. (This is a Tygon® connector/Teflon® tube attachment that is slipped over the Schrader® valve and secured to the valve with a pair of locking pliers.)
- 3.5.5 Resume power to pump and open some faucets as described in 3.3.3.

SOP Number: FSWA001.00

Previous SOP: None

Page 5 of 9

STANDARD OPERATING PROCEDURE

Well Sampling: Obtaining Permission to Sample, Purging, Collection, Preservation, Storage, and Documentation

3.5.6 Let water flow through sampling tube for 20 seconds to flush out tube.

3.6 Sample Collection

- 3.6.1 While purging the well, a field blank sample is collected at the well site to check for potential contamination.
 - 3.6.1.1 Put on a pair of gloves to prevent contaminating samples.
 - 3.6.1.2 Bring the de-ionized (DI) water container and a plastic bag to be used as a ground cover to the sample site.
 - 3.6.1.3 Place the DI water container on the plastic bag and remove the lid from the field blank container.
 - 3.6.1.4 Rinse the field blank sample container if it does not contain a preservative. Keep the field blank container lid in one hand, support the DI container, and pour DI water into the field blank container held in the styrofoam pack.
 - 3.6.1.5 Fill the field blank container to the top with DI water and replace cap. (Add preservative first if required then add DI water. Avoid overfilling.)
- 3.6.2 It is time to collect your samples after the pump has run for a total of 10 minutes (completing the purge procedure).
 - 3.6.2.1 Rinse out sample containers (only the containers that are not pre-packaged with a preservative) with well water before attempting to collect the well sample.
 - 3.6.2.2 Either insert the Schrader® sampling tube or gently run water from a faucet into each bottle and fill the appropriate number of

SOP Number: FSWA001.00 Previous SOP: None

Page 6 of 9

STANDARD OPERATING PROCEDURE

Well Sampling: Obtaining Permission to Sample, Purging, Collection, Preservation, Storage, and Documentation

bottles with well water to the designated volume as defined by the lab liaison for analysis and/or storage requirements.

3.6.2.3 If no sample preservation is required, rinse a one-half pint jar with the well water and then fill the jar with well water for a pH measurement. Determine pH. (SOP EQWA002.00) Record data on the Chain of Custody.

3.6.2.4 Turn off faucets and power to pump if using a Schrader® valve sample port (See Section 3.7).

3.6.2.5 Replace gloves.

3.7 Replacing Schrader Valve Stem After Sample Collection

- 3.7.1 After completing sample collection, turn faucets off and turn power to the circuit box or switch box to the off position.
- 3.7.2 Detach the Schrader® sampling tube.
- 3.7.3 Reinsert the core stem into the Schrader® valve using a core stem remover.
- 3.7.4 Resume power to pump.
- 3.7.5 Open faucets to reduce the pressure in the storage tank until the pump turns on, then close the faucet(s) and allow the pump to run through one complete cycle to check that it is turning on and off properly and that there are no leaks from the Schrader® valve core.
- 3.7.6 Remove the plastic bag covering the point box.

SOP Number: FSWA001.00

Previous SOP: None

Page 7 of 9

STANDARD OPERATING PROCEDURE

Well Sampling: Obtaining Permission to Sample, Purging, Collection, Preservation, Storage, and Documentation

3.8 Package Samples (Refer to SOPQAQC005.00)

3.9 Documentation

- 3.9.1 Prepare a chain of custody record (Appendix 2) to accompany each water sample and field blank as described in SOPADMN006.00.
- 3.9.2 Prepare a Well Water Summary Sheet (DWR Form 429) to request a California Well Number (Appendix 3). Note the owner, owner address, tenant, tenant address, county, township, range, section, well use, and pump type, and prepare a map showing the well location with respect to the nearest intersection. Plot the well location on a U.S. Geological Survey 7 1/2 minute topographical quadrangle map and attach it DWR Form 429.
- 3.9.3 Prepare a well information sheet to document the assessment information discussed in Procedure 3.2.2. Include micro and macro sketches of well location and construction. Note land use surrounding the well. Take close-up and vicinity photographs and attach to the well information sheet. Note the well owner's last name, study number, township/range-section, date sampled, and the sampling crew's initials on each photograph. Also, circle the sampling port and any important details and/or features regarding the well's condition or it's proximity to surrounding features.

4.0 STUDY SPECIFIC DECISIONS

- 4.0.1 Number of wells to sample: This depends on the analyte that is under evaluation and the type of study that is being performed. Refer to the appropriate well monitoring study protocol (four section, adjacent section, or ground water protection list) to determine the number of wells that are required for the study.
- 4.0.2 Number of samples to collect: This depends on the analyte that is under evaluation and the type of study that is being performed. Refer to the appropriate well monitoring study protocol (four section, adjacent section, or

SOP Number: FSWA001.00 Previous SOP: None

Page 8 of 9

STANDARD OPERATING PROCEDURE

Well Sampling: Obtaining Permission to Sample, Purging, Collection, Preservation, Storage, and Documentation

ground water protection list) to determine the number of samples that are required to be collected for each analyte per well in the study. A minimum of three replicate samples (one primary and two back-up samples) and a field blank sample should be collected for each set of analyses per well site.

4.0.3 Sample containers: Options include but are not limited to one-liter amber glass bottles, volatile organic analysis (VOA) vials, or one-liter polypropylene bottles. This choice depends on the analyte that is under evaluation. The Quality Assurance Officer will determine the appropriate container to be used after considering certain factors such as the type of analysis that is required and the volume of water that is required for analysis and the breakdown behavior of the compound versus factors such as light, temperature, and time. In addition, the Quality Assurance Officer needs to consider if the analyte will bind to the surface of any of the sample containers.

4.0.4 Sample Preservation

- 4.0.4.1 Acidification: Options are yes or no. The Q.A. officer will determine if acidification is required after considering the stability of the compound before it arrives to the laboratory for analysis. If hydrochloric acid is required, followed SOP FSWA007 for sample preservation.
- 4.0.4.2 Ice materials: Options include but are not limited to bags of crushed ice, dry ice, or blue ice. This choice depends upon the sample container that was selected, the volume of water in the container, and the temperature that the sample needs to be stored at during transportation to the laboratory and the method of transportation (ground or air freight).

SOP Number: FSWA001.00 Previous SOP: None

Page 9 of 9

STANDARD OPERATING PROCEDURE

Well Sampling: Obtaining Permission to Sample, Purging, Collection, Preservation, Storage, and Documentation

5.0 REFERENCES

APPENDIX 1: Department of Pesticide Regulation Permission Form For Request to Sample on a Property

APPENDIX 2: Department of Pesticide Regulation Chain of Custody Form Record

APPENDIX 3: Department of Water Resources Well Data Form 429

APPENDIX 4: Department of Pesticide Regulation Well Information Form

James M. Strock, Secretary for Environmental Protection

Pete Wilson, Governor

DEPARTMENT OF PESTICIDE REGULATION James W. Wells, Director

1020 N Street, Room 161 Sacramento, California 95814

Date _	
County	



The California Department of Pesticide Regulation requests permission to enter your property and obtain Well Water Samples. You are not liable for any personal injury or damage to our equipment which occurs on your property.

Should questions or problems arise, please call the Environmental Hazards Assessment Program at (916) 324-4100 (please call collect) and ask for the Well Information Contact.

Environmental Hazards Assessme	nt Program
Signature Granting Permission	
XOwner	(), Manager (), or()
Well I	nformation
Study # Lo	cation Code
State Well Number (T/R-S/TR/Se	q. No.)
Sampling Address	
	ZIP
Owner	Tenant
Mailing Address	Mailing Address
ZIP	ZIP
Phone No. ()	_ Phone No. ()
Contact Person	Contact Person
Is this the original well owne	r? Yes () No
Owner information: depth	
Positive for other chemicals?	No () Yes
	roperty? No () Yes

CALIFORNIA
DEPARTMENT OF
PESTICIDE REGULATION

CHAIN OF CUSTODY RECORD (use ball point pen only)

SPECIAL "Z" STUDY

ENVIRON. MONITOR. & PEST MGMT. ENVIRON. HAZARDS ASSESSMENT 1020 N STREET, ROOM 161 SACRAMENTO, CA 95814-5624

30-014 (Rev. 1/97)

Study # Sample #	Well Number Twn Rng Sec Well Owner's	3 4 5 8 Sequence Number 5 8 Date Sampled Time \$\frac{5}{2} \frac{5}{2} \frac{7}{2} \frac^	Lab Single Code Single (Save Extracts)
Person Collecting Partner Minutes Pumped pH/adjusted pH Location Code	Name 18 Address # Street City	ST CHEMICAL ST CHEMICAL AMOUNT p.p.b. ATRAZINE (0045) SIMAZINE (0531) DIURON (0231) PROMETON (0499) COMPARE COMPAR	DETECTION LIMIT
REMARKS: Primary 1 = Primary 2 = Backup = Backup = Field Blank 1 = Field Blank 2 =	Chemical Acronyms: DEA: 2-amino-4-chloro-6-isopropylamino-s-triazine ACET: 2-amino-4-chloro-6-ethylamino-s-triazine	BROMACIL (0083)	
Well Top Botto Depth Perf. Per	Method	Analyzed by: Approved by: Report Date:	
Task_ Container Preparation Collect/Transport Lab Name Receive	Relinquished b	Received by Logged in by Date/Time	Lab #

THE RESOL DEPARTMENT OF WATER RESOURCES

WELL DATA

SIRIE OF CACIFORNIA	_
URCES AGENCY OF CALIFORNIA	State No.

		WELL	DATA	BRANCH	
)wner			State No	•	
Address			Other No)	
Tenant					
Address					
Type of Well: Hydrograph [Index 🗀	Semiannual		No
J.S.G.S. Quad					
J.S.G.S. 4088	Santian T	ws	Rae	MD SB Base & Meridian	
	38C11011	" р		-H 2030 & morroran	
Description					
					
					
	· · · · · · · · · · · · · · · · · · ·				
Reference Point description .				<u> </u>	
Reference roint description.					
			•		
which isft	· below land surface. G	Ground Elevati	on		f
Keterence Point Elev	Tr. Dererini	nea 110111			
Weil: Use	C。	ndition	· · · · · · · · · · · · · · · · · · ·	·····	Depthft
Casing, size	in., perforations		· · · · · · · · · · · · · · · · · · ·	T	
Measurements By: DWR	USGS USBR	County	Irr. Dist.	Water Dist. Cons	. Dist.
Chief Aquifer: Name					
Type of Material	Perm	. Ratina		Thickness	
Gravel Packed? Yes					
Supp. Aquifer					
Driller					· · · · · · · · · · · · · · · · · · ·
				/ 3 \	(.1
Date drilled					
Equipment: Pump, type					
Serial No.					Н.М. (3)
Power, Kind					No
H. P Motor S					End
Elec. Meter No		1			
Yield	G.P.M. Pumping level	1ft.	Prod. Rec. (1)	Pump Test (2)	Yield (3)
SK	KETCH			REMARKS	
		, , , , , , , , , , , , , , , , , , ,			
		ואו			
		ì			·
		i i	** · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·	

				······	
					
					
					
				·	
	•				
			l		
	•				
	•		l 		
•]		
			Recorded by:		
			Date		
			I		

WELL INFORMATION

30-035 (Rev. 9/93))		
STUDY NUMBER		WELL OWNER	
WELL #		CANDUNG	
LOCATION CODE		SAMPLING ADDRESS	
CHEMICAL(S)	Atrazine, Bromacil, Diuron, F	Prometon, Simazine	
WELL CONDITION CASING	YES	SHED (CONT.)	YES
	Ė	PESTICIDE STORAGE	
PVC		LIST	
STEEL			
OTHER			
CRACKS			-
RUST		PUMP TYPE	
HOLES		SUBMERSIBLE TURBINE	
DIAMETER -		JET	
CAP			
CRACKS		SAMPLE PORT	
RUST		TANK	
HOLES		PUMP	
OTHER		FAUCET	
CEMENT PAD	П	SCHRADER	Ц
CRACKS		STAND PIPE	
AREA FT 2		PRESSURE RELEASE VALVE	
HEIGHT		OTHER	
WELL LOCATION		OTHER MEHO	
CRACKS	C1	OTHER WELLS ON PROPERTY	
IN SOIL		DOMESTIC	
DEPRESSED		IRRIGATION	
BERMED		ABANDONED	П
SLOPE		TEMP. SHUT DOWN	
SOIL TYPE	· · · · · · · · · · · · · · · · · · ·	MONITORING	
HERBICIDE USE?	, _	OTHER	
		IN REFERENCE TO SAMPLE WELL _	FT.
SHED WOOD			
ALUMINUM		DATE	
		TIME	
GARAGE		SAMPLE NUMBERS	/
OTHER CONDITION		pH	
EXCELLENT	Г	WELL TYPE: Domestic Irrigation	Large Water System
GOOD		·	
		COMMENTS	
POOR			
AREA FT			
PESTICIDE USE IN SHED?			

ATTACH POLAROIDS

SKETCH	(INCLUD	E WELL ETC.)	HEAD,	SAMPLE	PORT,	TANK,	SLOPE,	WELL	CONDITION	, ANYTH	IING U	NUSUAL	SUCH	AS CI	RACKS,
				•											
			• •												
				. •											
			• , , -												
							+ 174 +								
٠.	5 . 5	in and the second			12.							t.			
					,										

·

SITE DESCRIPTION